

Philips  
Classic micro sound  
system

10 W

MCM166



## Enjoy music in great sound

with USB Direct

Delight yourself in fantastic sound from the truly compact and stylish Philips Micro Hi-Fi system MCM166. Enjoy your favorite MP3-CD tunes and USB Direct playback richly enhanced by powerful Dynamic Bass Boost.

### Multiple sources for more choices

- Play MP3/WMA-CD, CD and CD-RW
- Enjoy MP3/WMA music directly from your portable USB drives
- FM digital tuning to preset up to 20 stations
- MP3 Link for portable music playback

### Enrich your sound experience

- 12W RMS total output power

### Quality sound performance

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

# PHILIPS

# Highlights

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls

you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now

you can share your favorite moments with family and friends.

## MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



# Specifications

## Sound

- Output Power: 2 x 5W RMS
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control 4 modes
- Volume Control: Volume Control up/down
- Output power (RMS): 400W PMPO

## Loudspeakers

- Main Speaker: 3" woofer

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

## Connectivity

- Headphone: 3.5 mm

- Other connections: FM fixed pigtail antenna
- USB: USB host
- 3.5mm stereo line in: MP3 Link

## Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue

## Accessories

- Remote control: 36-key remote control
- User Manual: B-Portugese, Spanish.
- Quick start guide: Spanish, B-Portuguese
- Cables: MP3 Line in cable

## Dimensions

- Set dimensions (W x H x D): 147 x 231 x 209 mm
- Main speaker dimensions (W x H x D): 134 x 233 x 153 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 5.1 kg

## Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2014-02-13

Version: 1.0.1

12 NC: 8670 000 70475  
EAN: 87 12581 57723 0

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Avoid extensive use of the set in a volume higher than 85 decibel  
because this may damage your hearing.