

Philips
Docking Entertainment
System with Dynamic Bass
Boost

USB Direct

FM digital tuner MP3 Link



DC185

Enjoy iPod and MP3 music out loud anywhere you go

Free your iPod music and enjoy it out loud on the Philips DC185 with powerful 2×2 W sound. Share all your tunes and liven up any party or just plug in your USB device to enjoy your favourite music on the go.

Enrich your sound experience

- Play and charge your iPod
- USB Direct for MP3/WMA music playback

Superb performance in a compact design

- Dynamic Bass Boost for deep and dramatic sound
- 2 x 2 W RMS total output power

Easy to use

- FM digital tuning with presets
- Aux-in connection for your portable MP3 music player



Specifications

iPod compatibility

 Compatible with: iPod touch, iPod classic, iPod nano 3rd Generation, iPod 5th Generation, iPod with colour display, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation

Connectivity

- USB: USB host
- Aux in
- Headphones: 3.5 mm

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and reverse
- Playback Media: USB flash drive
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store
- · Auto digital tuning
- Station presets: 20
- · Antenna: FM Antenna

Sound

- Output power (RMS): 2 x 2 W
- Sound System: Stereo

- Loudspeakers
- Built-in speakers: 2

• Speaker diameter: 3"

Convenience

- Display Type: LCD
- User convenience: Sleep Timer

• Sound Enhancement: Dynamic Bass Boost

• Volume Control: Volume Control up/down

Power

- Mains power
- Battery type: C/LR14 Alkaline
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

 Included accessories: AC Power Cord, 3.5 mm stereo line-in cable, User Manual, Warranty certificate

Dimensions

- Product dimensions (W \times H \times D): 348 \times 127 \times 238 mm
- Packaging dimensions (W \times H \times D): 373 \times 157 \times 262 mm









Highlights

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play and charge your iPod



Enjoy your favourite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favourite music in superb quality. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.



Issue date 2010-08-19

Version: 1.0.2

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 41722 EAN: 87 12581 43816 6

www.philips.com