

Philips
Micro Hi-Fi System



DCM278



Sleek Music System

wall-mountable design fits any decor

Play back your iPhone/iPod music in superb sound while recharging it with the Philips Micro Hi-Fi system DCM278. The flat, compact design is also wall-mountable to complement any interior. USB direct for added playback options.

Enjoy your music from multiple sources

- Play and charge your iPod/iPhone simultaneously
- Enjoy MP3/WMA music directly from your portable USB drives
- FM digital tuning to preset up to 20 stations
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 10 W RMS total output power

Design that blends into your interior(s)

- Stylish slim design with table-stand and wall-mount options
- Motorised sliding front door adding style and elegance

PHILIPS

Highlights

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can

enjoy consistent sound even when you turn down the volume.

Play and charge your iPod/iPhone



Enjoy your favourite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

Table-stand/wall-mount options



The perfect combination of a slim and versatile design, your Philips audio system is cleverly designed to blend into your living space. The base of the audio system is a stand so the system can sit securely and nicely on any shelf

or cabinet. When wall mounted you have all the same flexibility of the freestanding stand.

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

Motorised sliding front door



A motorised sliding front door adds even more panache to the already sleek design of this system. The stylish yet functional door housing the disc slides up and down vertically in a smooth motion at the touch of a button whenever you feel like changing your music selection. Just sit back and enjoy the dynamic sound performance while watching the disc play through the transparent window.



Specifications

Sound

- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Volume Control: Volume Control up/down
- Output power (RMS): 2 x 5 W

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer
- Built-in speakers: 2

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable, Fast Forward/Reverse, Next/Previous Track Search
- Loader Type: Front, Motorised
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop
- Cradle playback mode: Charging iPhone, Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause, Menu, Up and Down

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store
- Station presets: 20
- RDS: Programme Type, RDS Clock Set, Station Name
- Antenna: FM Antenna

Connectivity

- Headphones: 3.5 mm

- Other connections: FM fixed pigtail antenna
- 3.5 mm stereo line in: MP3 Link

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm, iPod Alarm
- Clock: On main display
- Display Type: LCD

Accessories

- Included accessories: World Wide Warranty leaflet
- Quick start guide: English
- Remote control: 31-key remote
- User Manual: English
- Cables: MP3 line-in cable

Dimensions

- Packaging dimensions (W x H x D): 614 x 310 x 159 mm
- Set dimensions (W x H x D): 542 x 238 x 102 mm
- Weight incl. Packaging: 5.4 kg

Power

- Power supply: 220-240 V, 50 Hz

iPod compatibility

- Compatible with: iPod, iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod with colour display, iPod 5th Generation, iPod touch 3rd generation, iPod touch 4th generation

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS



Issue date 2013-05-10

Version: 2.0.4

12 NC: 8670 000 76369
EAN: 87 12581 60322 9

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com