

Philips
Cordless phone answer
machine



DECT515S

The smart choice

Reliable quality coupled with practical features: this classic design with its modern touch makes the DECT515 really special.

Light up your calls

- Display for numbers, letters, icons and drawings
- LCD screen with backlighting for convenience in the dark
- Polyphonic ringtones for a more natural and realistic sound

Benefit from easy-to-use technology

- Answering machine control from base and handset
- Clock alarm timer
- Lock your keypad to avoid hitting the wrong keys
- Pilot key & carousel menu navigates in a menu-in-cycle form

PHILIPS

Specifications

Picture/Display

- Backlight
- Backlight color: Orange
- Diagonal screen size - tele: 4.0 cm
- Effective viewing area: 31.5x21
- Lines of text: 4

Sound

- Base station ringers: Polyphonic
- Handset ringers: Polyphonic
- Volume Control: digital

Convenience

- Auto out of range warning
- Base Station keys: Paging key
- Battery charging indication
- Battery full indication
- Battery low indication
- Call Management: Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting, Caller ID, Conference Call, Explicit Call Transfer, Microphone mute, Missed Calls, Received Calls
- Carousel Icons: Phonebook, Answerphone, SMS, Intercom, Network, Extra, Base, Handset, Call log
- Drop proof: 120 cm
- Ease of Use: Hands free mode, Hot Keys, Keypad Lock
- Function: Do not disturb ringer mute, Call cost, Alarm clock, Babysit function, Microphone mute, Conference call, Chain dialling, Direct to Do Not Disturb mode, Short cut keys, Keypad lock, Free handset to handset call
- Handset Keys: Line, Pilot key, Cancel / Recall, Dialling keypad, Loudspeaker, Call log, Phonebook
- Lines of text: 4
- Multi handset capability: Up to 6 handsets
- Text input: Eatoni
- VIP group with own melody: Yes, 3 groups
- Volume control

Accessories

- AC/DC Adaptor
- Batteries: 2 x AAA
- Cables: RJ 11 cable
- User Manual

Related Products

- Package contents: Handset, Base, 2 AAA NiMh Batteries, Telecom Line Cord, Power adapter, User Manual, Warranty leaflet, Sticker

Green Specifications

- Chemical composition: Nickel-Metal Hydride
- Eco Designed
- Halogen-free housing

- Packaging material: Carton
- Packaging type: Giftbox
- PVC-free product and cables
- User manual: Recycled paper

Dimensions

- Antenna: Integrated
- Base dimensions: 118x130x60
- Base weight: 180g
- Form Factor: Semi lying on base station
- Handset color: silver shadow
- Handset dimensions: 120mm
- Handset weight: 100g
- Packaging dimensions (W x H x D): 262 x 90 x 217 mm
- Relative humidity (operation): up to 95% at 40°C
- Relative humidity (storage): up to 95% at 40°C
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -25°C to 70°C

Power

- Ambient temperature: 5 °C to 40 °C
- Battery Type: NiMH
- Charging time: 14 hours hr
- Kind of Battery: Rechargeable
- Number of batteries: 2
- Power supply base station: 230V
- Radio RF power: <250mW
- Standby time: 200 hours
- Talk time: up to 15 hours

Network Features

- Antenna: Fast Selection Technology, Integrated on base, Integrated on handset
- Compatible: GAP, PABX
- Dialing: Tone, Pulse
- Messaging: Quick SMS

Operator Requirements

- Name and Caller ID
- Caller ID on call waiting
- Operators services phonebook

Answering Machine

- Plug & Play Answering machine
- Recording time capacity: 60 min
- VIP outgoing message
- Call screening
- Answerphone remote access

Memory Capacity

- Name & number shared phonebook: 65
- Melody download capacity: -
- SMS storage capacity: 25
- Call log entries: 40

Highlights

Full graphic display

This type of displays makes it easier to use your phone, thanks to the good quality and legibility of the characters. It also gives you more freedom in communication from your home. Now you can combine text with images or numbers, when sending an SMS for example.

Backlight on screen

Backlighting is a feature that illuminates the LCD screen or keypad for use in the dark. The two most common types of backlighting include LED and electroluminescent (EL). Remotes backlit with LEDs are typically bright but uneven with a yellow or green color, while EL panels are smooth with blue, white or green shades.

Polyphonic ringtones

A polyphonic ringtone means that the phone can play many tones simultaneously, so that an accurate musical performance is possible, and when played through the phone's speaker these polyphonic ringtones sound like real music.

Base and handset TAM control

Just look at the base station to know instantly whether you received messages. Listening or deleting messages then become as simple as pressing one key on the base station - for those who never remember where they left their handset.

Clock alarm timer

Clock alarm timer

Keypad lock

How convenient it is to take your DECT phone with you whilst gardening. But in your pocket it can be so jolted that a key might be accidentally pressed. To prevent inadvertently calling your cousin in the US, the keypad lock is a safe way to avoid bad surprises on your next phone bill!

Pilot key & carousel menu

The pilot key navigation system allows easy navigation and settings. The pilot key is a roller on the left side of the phone that can be scrolled up and down and pressed in the middle. It commands the Carousel menu which is a circular loop of menu icons displayed on the screen.



Issue date 2014-02-05

Version: 3.0.5

12 NC: 9961 400 02792
EAN: 87 10895 83683 8

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com