

Philips
Cube micro sound system

dock for iPhone/iPod

DCM109



Obsessed with sound

Sound that fits your home

Dock your iPhone/iPod player. Listen to your music from one simple control. Great sound and stylish design. Sit back and relax, enjoy your music all day, your way.

Enjoy your favorite music

- iPod/iPhone music playback and recharge
- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for easy MP3 music playback
- FM digital tuning with presets

Superb sound quality

- Dynamic Bass Boost for deep and dramatic sound
- 10W RMS total output power

Design that blends into your interior

- Compact design fits any space, any lifestyle
- Integrated dock for portable music enjoyment without clutter

PHILIPS

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop
- Docking playback modes: fast forward and backward, next and previous track, play and pause

Sound

- Output power: 2 x 5 W RMS
- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down

Loudspeakers

- Speaker drivers: 3.5" woofer
- Speaker types: bass reflex speaker system

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Tuner enhancement: auto digital tuning

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm, iPod alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: top

- Display type: LCD display
- Backlight color: white
- Charging device: iPhone, iPod

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th generation, iPod touch, iPod classic, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod touch 2nd generation

Accessories

- Cables/Connection: MP3 Link cable
- Remote control
- User Manual: multi-languages
- Others: Quick start guide
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 5.48 kg
- Main speaker dimensions (W x D): 150 x 197 mm
- Main speaker height: 152 mm
- Main unit depth: 250 mm
- Packaging width: 531 mm
- Main unit height: 152 mm
- Packaging height: 302 mm
- Main unit width: 150 mm
- Packaging depth: 202 mm

Power

- Power supply: 50 Hz
- Power supply: 220 - 240 V

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS



Highlights

iPod/iPhone music playback

iPod/iPhone music playback and recharge.

Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2014-02-12

Version: 1.0.5

12 NC: 8670 000 58749
EAN: 87 12581 51900 1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com