

High precision sound

Enjoy an authentic listening experience in style. Created to offer outstanding performance through open back architecture and high-precision 50mm speaker drivers.

#### **Supreme listening experience**

- Exquisite open-back, over the ear design for authentic sound
- 50mm neodymium drivers deliver the full spectrum of sound
- Angled drivers align perfectly with your ear

## Comfortable for long wearing

- Breathable ear cushion for longer wearing comfort.
- · Steel headband for strength and durability
- · Comfortable double layered headband cushion

#### Convenience

• 1.5m cable gives you freedom of movement for indoor use

Philips HiFi Stereo Headphones

50mm drivers/open-back Over-ear

## **SHP9500S**







# Highlights

## 50mm neodymium speaker drivers



50mm neodymium speaker drivers deliver superior Hi-Fi sound.

#### **Breathable ear cushions**



Deluxe breathable ear-pads improve breathability and dissipate pressure and heat for longer wearing comfort.

#### Comfortable headband cushion



Comfortable double layered headband cushion

#### **Durable steel headband**



Steel headband for strength and durability

## Open-back, over-ear headphones

An acoustic open-back architecture eliminates air pressure build-up behind the driver, giving the diaphragm greater freedom of movement. This greatly enhances sound transparency and smoothens extended high frequencies.

## **Precisely angled drivers**

Engineered to fit the ear's natural geometry, the earshells offer precise and accurate sound. Audio signals are directly channeled into the ears, creating a dynamic and authentic listening experience.

### 1.5m cable for freedom

1.5m cable gives you freedom of movement for indoor use

# Specifications

#### Sound

- Acoustic system: Open
- Magnet type: Neodymium
- Impedance: 32 ohm
- Maximum power input: 200 mW
- Speaker diameter: 50 mm
- Frequency response: 6 35 000 Hz
- Sensitivity: 102

#### **Connectivity**

- · Cable Connection: one-sided
- Cable length: Detachable 1.5 m cable included
- Finishing of connector: Rubber finishing

### **Product dimensions**

- Product dimensions (W x H x D): 6.7 x 7.9 x 3.9 inch
- Product dimensions (W x H x D): 17 x 20 x 10 cm
- Weight: 0.33 kg
- Weight: 0.728 lb

## **Outer Carton**

- Gross weight: 5.004 lb
- Gross weight: 2.27 kg
- GTIN: 1 08 89446 00650 3
- Outer carton (L x W x H):  $37.5 \times 21 \times 23.5$  cm
- Outer carton (L  $\times$  W  $\times$  H): 14.8  $\times$  8.3  $\times$  9.3 inch
- Number of consumer packagings: 3
- Tare weight: 2.822 lb
- Tare weight: 1.28 kg
- Nett weight: 0.99 kg
- Nett weight: 2.183 lb

## **Packaging dimensions**

- Packaging dimensions (W x H x D): 7.7 x 8.9 x 4.7 inch
- Packaging dimensions (W x H x D): 19.5 x 22.5 x 12 cm
- Gross weight: 1.455 lb
- Gross weight: 0.66 kg
- · Nett weight: 0.728 lb
- Nett weight: 0.33 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 0.728 lb
- Tare weight: 0.33 kg
- Type of shelf placement: Both
- UPC: 8 89446 00650 6



Issue date 2017-08-11

Version: 2.0.5

© 2017 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 37643 UPC: 8 89446 00650 6

www.philips.com