



Philips  
PhotoFrame

8" LCD  
4:3 frame ratio

8FF3CDW



## Share your memories

How many digital pictures are hidden on your PC? See, share, organize and relive your memories with Philips PhotoFrame™, the easiest way to display your digital photos in stunning quality - without a PC.

### Top quality display for print-like pictures

- 4:3 aspect ratio for optimal distortion-free display
- imagen Pro for sharper and vibrant colors
- Add new glow to old memories with RadiantColor

### Easily display and manage your digital photos

- An additional SD card slot for unlimited memories
- Have fun with Collage Pro: automatically or edit by yourself
- An easy drag and drop PC software to transfer your photos
- Create albums, slideshows and manage your photos

### Simple intuitive operation and great convenience

- Auto photo orientation to fit portrait or landscape modes
- Power saving via auto dimming by detecting ambient lighting

### Classic design: real materials and fine texture

- Real wood front with natural grain - designed for your home

# PHILIPS

# Highlights

## 4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

## Unlimited memories

Your Philips PhotoFrame comes with an additional SD card slot enabling you to expand the storage space on your PhotoFrame offering plenty of space for all your memories - it's like having virtually unlimited space for your memories and photos! Also thanks to the Philips Memory card manager, you can easily copy and paste images between all your various types of memory cards.

## Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.

## Collage Pro

Remember the fun you had working with your photos in the past - such as cutting them and creating nice collections! Collage Pro is a unique and advanced feature provided by Philips digital PhotoFrame. Just like on other Philips digital PhotoFrames with Collage function, you can run collage slideshows automatically (random view). With Collage

Pro, you can also edit and create collages by yourself. You can also easily create a collage even from multiples sources such as an SD card or USB pen drive.

## imagen Pro

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

## PhotoFrame Manager

You can easily connect your Philips PhotoFrame to your computer via a USB cable. The PhotoFrame Manager is a simple to use drag and drop software tool that allows you to simply drag your photos from your computer to your PhotoFrame - it's really that simple! On top of this, the software enables simple editing like zoom and crop. You can even preview what you have edited before transferring to your PhotoFrame.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## Real wood with natural grain

There are plenty of digital photo frames in the market with ugly, gadget typ designs. They won't fit my home interior at all. Now, Philips comes with a PhotoFrame with a real wood front with a warm color and natural grain which perfectly fits the simple and clean rear cover design. It not also suits your home decor but brightens up any room!

## Smart Album

Smart Album allows you to create and manage albums, as well as to set up and adjust transition effects to your photo slideshows.

## Smart Power Pro

Smart Power Pro is a sensor that turns PhotoFrame on and off by detecting ambient lighting condition reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. The best news is that this is all done automatically!



# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 130° (H) / 110° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m<sup>2</sup>
- Contrast ratio (typical): 300:1

## Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

## Storage Media

- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo
- USB: USB flash drive
- Built-in memory capacity: 128MB (for 510-1020 photos, around 26MB used by system)

## Convenience

- Card Reader: Built-in (3x)
- Photo format supported: Up to 10MB JPEG files, Up to 20 Megapixels, JPEG photo
- Placement supported: Landscape, Portrait, Photo auto orientation
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Radiant color, Sepia
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Screen background: Black, White, Gray, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Beep on/off, Set time and date, Clock display enable/disable, Auto on/off, Event reminder with snooze, Photo source, Slideshow
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Plug & Play Compatibility: Windows 2000/XP or later, Windows Vista, Mac OS X

- Regulatory Approvals: C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL, BSMI
- On-Screen Display languages: Danish, Dutch, English, French, German, Italian, Russian, Simplified Chinese, Spanish
- Album management: Create, Delete, Edit, Rename
- Other convenience: Kensington lock compatible
- Slideshow management: Create slideshow, Delete slideshow, Rename slideshow

## Accessories

- Included Accessories: AC-DC Adapter, Quick start guide, Stand, USB cable, CD-ROM with software + manual

## Dimensions

- Weight: 0.34 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C
- Set dimensions with stand (W x H x D): 222.6 x 182.2 x 33.2 mm

## Power

- Power consumption: (System on) 5.09 W
- Power mode supported: AC powered
- Power source: DC output 9V, 2A
- Power supply: 100-240VAC, 50/60Hz

## Outer Carton

- Gross weight: 3.7648 kg
- Outer carton (L x W x H): 29.9 x 24.8 x 24.8 cm
- Nett weight: 1.9988 kg
- Tare weight: 1.766 kg
- GTIN: 1 87 12581 41237 8
- Number of consumer packagings: 2

## Packaging dimensions

- Packaging dimensions (W x H x D): 27.8 x 22.9 x 10.7 cm
- Gross weight: 1.632 kg
- Nett weight: 0.9994 kg
- Tare weight: 0.6326 kg
- EAN: 87 12581 41237 1
- Number of products included: 1
- Packaging type: Carton



Issue date 2021-08-16

Version: 3.0.7

12 NC: 8670 000 39018  
EAN: 87 12581 41237 1

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)