



Philips
docking speaker

for iPod/iPhone

AD200

Enjoy music from your iPod/iPhone

Whether on your desk or somewhere else, this dashing docking speaker delivers crystal-clear sound that fills your personal space.

Crystal clear sound

- Neodymium speakers for pure balanced sound
- Bass Reflex Speaker System delivers a powerful, deeper bass

Enjoy your favourite music

- Play and charge your iPod/iPhone simultaneously
- Aux-in connection for your portable MP3 music player

Elegant and compact

- Compact design for any space, any lifestyle

PHILIPS
sense and simplicity

Specifications

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod compatibility

- Compatible with: iPod, iPod classic, iPod mini, iPod nano, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation, iPod touch, iPod touch 2nd generation, iPod touch 2nd gen 8/16/32 GB, iPod with colour display, iPod 5th generation

Sound

- Sound system: stereo
- Volume control: up/down
- Output power: 4 W RMS

Connectivity

- MP3 Link: 3.5 mm stereo line in

Loudspeakers

- Speaker drivers: Neodymium magnet system
- Loudspeaker enhancement: bass reflex speaker system

Power

- Power supply: 100 - 240 V AC, 50/60 Hz

Dimensions

- Packaging dimensions (W x H x D): 28.5 x 8.5 x 11.1 mm
- Product dimensions (W x H x D): 185 x 64 x 94 mm
- Product weight: 0.43 kg
- Gross weight: 0.56 kg
- Master carton quantity: 4
- Master carton weight: 2.52 kg

Convenience

- Charging device: iPhone, iPod

Accessories

- AC/DC Adapter: 110 V-220 V



Highlights

Neodymium speakers

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and a pure balanced sound quality.

Compact design

Compact design for any space, any lifestyle

Aux-in connection



Aux-in connection for your portable MP3 music player

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Play and charge your iPod/iPhone



Enjoy your favourite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

* iPhone is required in order to use the speaker phone functionalities



Issue date 2013-03-03

Version: 3.0.6

12 NC: 8670 000 78531
EAN: 87 12581 60879 8

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com