

Philips
CD Soundmachine with
Dynamic Bass Boost

MP3

AZI316



all-in-one, impressive MP3 music

Compact and stylish, this all-in-one CD player plays all CDs, including MP3-CD. Sit back and enjoy music convenience with its programmable 20 track replay.

Feature-packed CD player

- MP3-CD, CD-R/RW compatible
- CD shuffle/program/repeat

Impressive sound

- Dynamic Bass Boost for deep and dramatic bass
- Bass Reflex speakers deliver a powerful, deeper bass

Easy to use and precise control

- Digital tuning with presets
- Auto store Programming for one-touch radio tuning
- Remote control

PHILIPS
sense and simplicity

Specifications

Sound

- **Output power (RMS):** 2X1.2W
- **Sound System:** Stereo
- **Volume Control:** Volume Control up/down
- **Speaker diameter:** 4"
- **Loudspeaker types:** Bass Reflex Speaker System
- **Sound Enhancement:** Dynamic Bass Boost

Audio Playback

- **Loader Type:** Top
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD
- **Disc Playback Modes:** Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- **Programmable Tracks:** 20
- **Number of decks:** 1
- **Cassette Deck Technology:** Mechanical
- **Cassette Playback Modes:** Fast wind / rewind, Full Auto Stop, Pause key

Tuner/Reception/Transmission

- Auto digital tuning
- **Station presets:** 20

- **Antenna:** AM antenna, FM Antenna
- **Tuner Bands:** FM, MW

Convenience

- **Display Type:** LCD
- **Remote control:** 14 keys

Accessories

- **Included Accessories:** AC Power Cord, User Manual, Warranty certificate

Power

- Mains power
- **Battery type:** LR14
- **Battery voltage:** 1.5 V
- **Number of batteries:** 6

Dimensions

- **Packaging dimensions (W x H x D):** 470 x 275 x 210 mm
- **Product dimensions (W x H x D):** 400 x 243 x 169 mm
- **Weight:** 2.9 kg
- **Weight incl. Packaging:** 3.7 kg

Product highlights

MP3-CD,CD-R/RW compatible

CD shuffle/program/repeat

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Digital tuning with presets

Auto store programming

Auto store Programming is a convenient feature that allows you to tune in to your favourite stations and set station presets by simply pressing a button. Auto store Programming does away with the hassle of manual radio station tuning and setting of presets. A built-in electrical circuit automatically scans local radio station frequencies, locks on to the strongest radio station signals, and assigns them to specific presets.

Remote control



Issue date 2007-12-06

Version: 2.0

12 NC: 9073 101 02248
EAN: 87 10895 91952 4

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com