

Philips CD Soundmachine with Dynamic Bass Boost

DVD Karaoke USB



AZ5836

Enjoy your favorite DVD

Movies, photos and music

You can now enjoy favorite movies, music and even photos on your TV with the all-inone DVD Soundmachine AZ5836. Immerse in powerful sound with Bass Reflex speakers and 2x4W total output power. For more music options, there's USB Direct.

Everything you need

- Karaoke for endless singing entertainment
- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- USB Direct for MP3/WMA music playback

Powerful sound you can hear and feel

- MAX Sound for instant power boost
- Bass Reflex Speakers for a deep, powerful sound

Easy to use

- Digital tuning with preset stations for extra convenience
- · Handy remote control for extra convenience
- Auto-stop stereo tape deck



Specifications

Sound

- Equalizer: 3-bands
- Loudspeaker types: Bass Reflex Speaker System
 Sound Enhancement: MAX Sound, Treble and Bass
- Control, Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: Volume Control rotary/encoder
 Output power (RMS): 2x4.0W
- Output power (RMS): 2

Loudspeakers

- Finishing: Metal
- Built-in speakers: 2
- Loudspeaker Enhancement: Max BASS Port
- Loudspeaker types: Loudspeakers

Video Playback

- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, Introscan, OSD, Pause, PBC, Slow Motion, Zoom
- Playback Media: DVD+R/+RW, DVD-Video, Picture CD, Video CD/SVCD

Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1





Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning
- Tuner Bands: FM, MW

Connectivity

- Audio output: Stereo Audio (3.5 mm jack) 1x
- Headphone: 3.5 mm
- Video Output Analog: Video (3.5mm jack) 1x
 USB: USB host

Convenience

Backlight

- Backlight color: Amber
- Display Type: LCD

Accessories

- Included accessories: AC Power Cord, Audio/
- Video cable, User Manual, Warranty certificate
- Remote control

Dimensions

PICTURE

CD

- Packaging dimensions (W \times H \times D):
- 548 x 345 x 210 mm • Product dimensions (W x H x D):
- 520 x 178 x 287 mm • Weight: 4.1 kg
- Weight incl. Packaging: 5.4 kg



AZ5836/58

Highlights

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

Bass Reflex Speakers

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

Auto-stop stereo tape deck

Auto-stop stereo tape deck

Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.

PlayDVD,VCD,MP3-CD,CD(RW)&Pict

The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.



Issue date 2014-02-07

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.7

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 37291 EAN: 87 12581 40864 0

·

www.philips.com