

Philips
Mini Hi-Fi System

FWT9200MU

Powerful wireless music

Obsessed with sound

Sass up music enjoyment on the FWM9000 with 1980W RMS and 19900W PMPO, dual subwoofer for deep bass, multi-colored disco lights and UniSound for clear natural sound. Also enjoy access to USB devices and Rip-plus for one-touch MP3 recording.

Powerful sound you can hear and feel

- Dual subwoofers for superb deep bass
- MAX Sound for instant power boost
- Dynamic lighting for dancing to the beat
- UniSound for natural and crystal-clear sound
- 19900W PMPO/ 1980W RMS total output power

Multiple source MP3 music

- Compatible with MP3-CD
- Dual USB Direct for MP3 playback and transfer
- Rip music from CDs, radio and karaoke onto USB device
- MP3 Link for portable music playback
- · Optional dock for convenient playback from your iPod/iPhone

Easy to use

- Music transfer between 2 USB for easy music sharing
- 3-disc changer for convenient multi-disc playback



Highlights

MAX Sound



MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do

is to plug your portable MP3 player to the audio system.

3-disc changer



With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

Dual USB Direct

Dual USB Direct for MP3 playback and transfer

Rip music onto USB device



Rip music from CDs, radio and karaoke onto USB device

UniSound



Get ready for music that is undeniably clearer and more natural. The UniSound technology harnesses acoustic design and engineering expertise to deliver sound the way it was meant to be heard. In conventional speakers, the tweeter and woofer deliver sound from different locations. This creates strong interferences that distort sound, resulting in unnatural, flat and stifled audio. UniSound frees music by placing the tweeter and woofer in unique positions and incorporating rigorous crossover engineering, vastly reducing interference and delivering natural sound that is true to the original.

Optional dock



Attach this dock to your home theater system and you can enjoy your music, videos and pictures from your iPod devices and iPhone. Dock is sold as an optional accessory.









Specifications

Sound

- Output power: 19900 W PMPO
- Total Sound Power (RMS): 1980 W
- Sound enhancement: MAX sound, Dynamic Bass Boost 3 steps, incredible surround, digital sound control 4 modes, virtual ambience control, UniSound

Loudspeakers

- Number of speaker boxes: 6
- Speaker drivers: 8" woofer, 2" tweeter
- Subwoofer types: 10" woofer, passive
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD
- Disc playback modes: repeat/one/all/program, repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop

Audio recording

- · Recording media: USB device
- USB recording sources: CD, tuner, AUX, microphone in, USB
- USB recording modes: instant record, programmed tracks, schedule radio program, single disc, single track

Tuner/Reception/Transmission

- Station presets: 40
- Tuner bands: FM, MW
- · Antenna: FM antenna, MW antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

Connectivity

• MP3 Link: 3.5mm stereo line in

- · Microphone: dual microphone sockets
- USB: Dual USB host
- PC in (Aux in): 2xRCA (Audio)

Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- Number of discs: 3
- · Loader type: 3 CD carousel
- · Clock: on main display, sleep timer
- Display enhancements: DIM mode
- Display type: VFD display
- · Karaoke: MIC volume, echo control

Accessories

- Remote control: 28-key with 2xAAA batteries
- Cables/Connection: MP3 Link cable, *Flat pin adaptor
- Others: batteries for remote control, FM/MW antenna, Quick start guide
- User Manual: B-Portuguese, Spanish
- Warranty: World Wide Guarantee booklet

Dimensions

- Main speaker dimensions (W x D): 258 x 388 mm
- Main speaker height: 450 mm
- Main unit width: 265 mm
- Main unit height: 377 mm
- Main unit depth: 456 mm
- Subwoofer width: 316 mm
- Subwoofer height: 450 mm
- Subwoofer depth: 456 mm
- Surround speaker width: 198 mm
 Surround speaker height: 375 mm
- Surround speaker depth: 267 mm

Power

• Power supply: 100 - 240V AC, 50/60Hz



Issue date 2013-10-18

Version: 1.0.3

© 2013 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 03013 EAN: 87 12581 68779 3 www.p

3 www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.