

Philips DVD player

## **DVP1013**



# Simply plays it all

Introducing a dream player that promises flawless, true-to-life picture quality and the ability to play virtually any disc! This Philips DVD player delivers your movies and music entertainment experience right in your personal environment.

## Bring audio and video to life

- 12-bit/108MHz video processing for sharp and natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- · High quality outputs for analog and digital audio
- · Progressive Scan component video for optimized image quality

## Play all your movies and music

- Plays MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW

## Fits any space, any lifestyle

• Ultra-slim design that fits anywhere



## DVP1013/37

## Specifications

#### Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

#### Sound

- Crosstalk (1kHz): 70 dB
- D/A converter: 24 bit, 192 kHz
- Dynamic Range (1kHz): 80 dB
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB

### Video Playback

- Compression formats: MPEG1, MPEG2
- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD, CD, DVD
- · Video disc playback system: NTSC, PAL

## **Audio Playback**

- Compression format: Dolby Digital, MP3, PCM, WMA
- Playback Media: Audio CD, CD-R/RW, CD, MP3-CD, MP3-DVD, WMA-CD
- MP3 bit rates: 32 256 kbps

## Still Picture Playback

• Picture Compression Format: JPEG

- Picture Enhancement: Flip photos, Rotate, Slideshow, Zoom
- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Kodak Picture CD, Picture CD

#### Connectivity

 Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, ComponentVideo out Progressive

#### **Accessories**

 Included accessories: 2 x AAA Batteries, Audio/ Video cable, Remote Control, Product Registration Card, User Manual, World Wide Warranty leaflet

#### **Dimensions**

 Packaging dimensions (W x H x D): 304 x 95 x 288 mm

#### Power

- Power consumption: < 10 W
- Power supply: 120V, 60Hz
- Standby power consumption: < 1 W

#### Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: Canadian French, English, Mexican Spanish

## Highlights

#### Plays it all

Play MP3s, WMA and JPEGs, and experience the convenience of sharing media files on your TV or home theater system - in the comfort of your living room

#### 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

### **Progressive Scan**

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.











Issue date 2014-02-06

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.10

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 31923 UPC: 6 09585 13688 5

www.philips.com