



Philips
Portable Radio

Digital Audio Broadcasting

AE5900



Digital radio with crystal clear sound quality

Digital radio with an elegant leather finish, the AE5900 also comes with line-in connectivity for your MP3 player. Its built-in alarm clock and cooking timer makes it an ideal bedroom or kitchen companion.

Enjoy digital quality DAB radio

- Interference-free DAB radio
- DAB and FM compatible for a full radio experience
- Line-in connection for your MP3 portable music player

Excellent sound reproduction

- Bass Reflex speakers deliver a powerful, deeper bass
- 4 W RMS total output power

Easy to use

- Built-in digital alarm clock with cooking timer
- 10 DAB and 10 FM preset stations
- Elegant leather finishing

PHILIPS
sense and simplicity

Specifications

Tuner/Reception/Transmission

- DAB: Band III, Info display, Smart Scan, Menu
- Tuner Bands: FM
- Station presets: 20
- Auto digital tuning
- Antenna: FM Antenna

Sound

- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 4 W RMS
- Volume Control: Volume Control rotary/encoder

Loudspeakers

- Built-in speakers: 1
- Main Speaker: 3" full-range woofer

Connectivity

- Headphones: 3.5 mm
- DC in: 9 V
- Audio Connections: 3.5 mm Line in

Convenience

- Display Type: LCD
- Backlight
- Alarms: Sleep timer, Repeat alarm (snooze)
- Backlight colour: White

Power

- Mains power

Accessories

- Included accessories: AC-DC Adapter, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D):
310 x 169 x 165 mm
- Product dimensions (W x H x D):
269 x 124 x 130 mm
- Weight: 2.4 kg
- Weight incl. Packaging: 2.6 kg

Highlights

Interference-free DAB radio

DAB (Digital Audio Broadcasting) digital radio is, in addition to FM analogue transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in crystal clear, crackle-free sound quality. The technology allows the receiver to lock onto the strongest signal it can find. With DAB digital stations there are no frequencies to remember and sets are tuned by station name, so there is no retuning on the move.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Built-in alarm clock with cook

Built-in digital alarm clock with cooking timer

10 DAB and FM preset stations

10 DAB and 10 FM preset stations



Issue date 2010-10-19

Version: 2.0.3

12 NC: 8670 000 31635
EAN: 87 12581 34684 3

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com