



Philips
Cordless phone answer
machine

DECT5154S

The smart choice

Reliable quality coupled with practical features: this classic design with its modern touch makes the DECT515 really special.

Light up your calls

- Display for numbers, letters, icons and drawings
- LCD screen has backlighting for convenience in the dark
- Polyphonic ringtones for a more natural and realistic sound.

Maximise your messaging experience

- Download ringtones from dedicated sites
- Text messaging (SMS) for short messages over a fixed line
- Eatoni predictive text entry simplifies writing SMS messages
- Obtain different types of messages for your answerphone

Benefit from easy-to-use technology

- Answering machine control from base and handset
- Alarm clock
- Lock your keypad to avoid hitting the wrong keys
- Pilot key & carousel menu navigates in a menu cycle form

PHILIPS
sense and simplicity

Specifications

Picture / Display

- Backlight
- Backlight colour: Orange
- Diagonal screen size - tele: 4.0 cm
- Effective viewing area: 31.5x21
- Lines of text: 4

Sound

- Base station ringers: Polyphonic
- Handset ringers: Polyphonic
- Volume Control: digital

Convenience

- Auto out of range warning
- Base station keys: Answering machine keys, Paging key
- Battery charging indication
- Battery full indication
- Battery low indication
- Call management: Call counters, Call forwarding, Call on hold, Call time, Call waiting, Caller ID, Conference call, Explicit call transfer, Microphone mute, Missed calls, Received calls
- Carousel Icons: Phonebook, Answerphone, SMS, Intercom, Network, Extra, Base, Handset, Call log
- Drop proof: 120 cm
- Ease of Use: Hands free mode, Hot keys, Keypad lock
- Function: Do not disturb ringer mute, Call cost, Alarm clock, Baby-sit function, Microphone mute, Conference call, Chain dialling, Direct to do not disturb mode, Short cut keys, Keypad lock, Free handset to handset call, Melodies download
- Handset keys: Line, Pilot key, Cancel / recall, Dialling keypad, Loudspeaker, Call log, Phonebook
- Lines of text: 4
- Multi handset capability: Up to 6 handsets
- Text input: Eatoni
- VIP group with own melody: Yes, 3 groups
- Volume control

Accessories

- AC/DC adaptor
- Batteries: 8 x AAA
- Cables: RJ 11 cable
- Charger: yes, 3 chargers
- User manual

Related Products

- Package contents: Handset, Base, 2 AAA NiMh batteries, Telecom line cord, Power adapter, User manual, Warranty leaflet, Sticker

Green Specifications

- Chemical composition: Nickel-Metal Hydride

- Eco-friendly designed
- Halogen-free housing
- Packaging material: Carton
- Packaging type: Gift box
- PVC-free product and cables
- User guide, recycled paper

Dimensions

- Antenna: Integrated
- Base dimensions: 118x130x60
- Base weight: 180g
- Form factor: Semi lying on base station
- Handset colour: silver shadow
- Handset dimensions: 120mm
- Handset weight: 100g
- Packaging dimensions (W x H x D): 262 x 90 x 217 mm
- Relative humidity (operation): up to 95% at 40°C
- Relative humidity (storage): up to 95% at 40°C
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -25°C to 70°C

Power

- Ambient temperature: 5 °C to 40 °C
- Battery type: NiMH
- Charging time: 14 hours hr
- Battery type: Rechargeable
- Number of batteries: 2
- Power supply base station: 230V
- Radio RF power: <250mW
- Standby time: 200 hours
- Talk time: up to 15 hours

Network Features

- Antenna: Fast selection technology, Integrated on base, Integrated on handset
- Compatible: GAP, PABX
- Dialling: Tone, Pulse
- Messaging: Quick SMS

Operator Requirements

- SMS
- Name and caller ID
- Caller ID on call waiting
- Operators services phonebook

Answering Machine

- Plug & Play answering machine
- Recording time capacity: 60 min
- VIP outgoing message
- Call screening
- Answerphone remote access

Memory Capacity

- Name & number shared phonebook: 65
- Melody download capacity: 3
- SMS storage capacity: 25
- Call log entries: 40

Product highlights

Full graphic display

This type of displays makes it easier to use your phone, thanks to the good quality and legibility of the characters. It also gives you more freedom of communication from your home. Now you can combine text with images or numbers.

Backlight on screen

Backlighting is a feature that illuminates the LCD screen or keypad for use in the dark. The two most common types of backlighting include LED and electroluminescent (EL). Remotes backlit with LEDs are typically bright but uneven with a yellow or green colour, while EL panels are smooth with blue, white or green shades.

Polyphonic ringtones

A polyphonic ringtone means that the phone can play many tones simultaneously, so that an accurate musical performance is possible, and when played through the phone's speaker these polyphonic ringtones sound like real music.

Ringtone download

This function offers the possibility to personalise your phone by downloading ringtones. Simply call the dedicated service provider and select your favourite song. An SMS is sent to you, together with the attached melody. You can select this melody as you would any other ringtones (country and network dependent).

Text messaging (SMS)

The Short Message Service (SMS) is a mechanism for delivery of short messages which can have up to 160 characters of text. These 160 characters are plain text in nature and can be comprised of words, numbers or an alphanumeric combination. The Eatoni®LetterWise predictive text editor helps you to write text messages more quickly. With its unique SMS system you can receive up to 200 messages in 10 different mailboxes.

Eatoni text editor

Eatoni's LetterWise is an easy to use text entry solution requiring just 1.16 taps per correct letter. It makes typing on phone keypads as comfortable, fast, and accurate as using a typewriter keyboard. It is unique among predictive text entry solutions in its ability to easily handle the entry of abbreviations, names, addresses, and URLs.

Downloadable outgoing messages

This function gives you the possibility to download specific outgoing messages for your answering machine. Simply call the dedicated service provider and select your favourite outgoing message. This message will be recorded on the answering machine by the service provider (country and network dependent).

Base and handset TAM control

Just look at the base station to know instantly whether you have received any messages. Listening or deleting messages then become as simple as pressing one key on the base station - for those who never remember where they left their handset.

Alarm clock

Keypad lock

In your pocket your DECT phone can be jolted and a key might be accidentally pressed. To prevent inadvertently calling your cousin in the US, the keypad lock is a safe way to avoid bad surprises on your next phone bill



Date of issue 2007-02-20

Version: 2.0

12 NC: 9961 400 03634
EAN: 87 10895 86209 7

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com