

Philips Portable DVD Player

18cm/ 7" LCD <sup>3hr playtime</sup> USB



PD7006B



# Your fun portable DVD

# with spill resistant design

Indulge in entertainment wherever you go. The portable PD7006 DVD player's spill resistant design makes it perfect for kids, letting them enjoy favorites without worry about spillage from drinks. Play your movies, music and photos anywhere.

# Play your movies, music and photos on the go

- DVD, DVD+/-R, DVD+/-RW, (S)VCD, CD compatible
- DivX Certified for standard DivX video playback
- MP3-CD, CD and CD-RW playback
- View JPEG images from picture disc

# Spill resistant design

- Easy clean rubber surface
- Protect your device from spilled water

## Extra touches for your convenience

- Enjoy up to 3 hours playback with a built-in battery  $\!\!\!\!\!*$
- USB connection for video, photo and music playback
- Full Resume on Power Loss
- Car adaptor included



# Highlights

## MP3-CD, CD and CD-RW playback



MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A singe CD can store up to 10 hours of music.

### View JPEG from picture disc



Play JPEG photos that are saved on your disc. Relive your favorite moments with family and friends anytime you want!

### DVD, DVD+/-RW, (S)VCD, CD



The Philips Portable DVD player is compatible with most DVD and CD discs available in the market. DVD, DVD+/-R, DVD+/-RW, (S)VCD, and CD – all of them can play on the DVD player. DVD+/-R is a shorthand term for a DVD drive that can accept both of the common recordable DVD formats. Likewise, DVD+/-RW handles both common rewritable disc types.

#### **Power Resume**

The DVD-Video player remembers where you stop watching last time when it is powered off directly or when the power supply discontinued. If you did not switch to play another disc, your player will resume play where you have stopped the movie last time just by reloading the disc. Making your life a lot easier!

### **DivX** Certified

With  $\mathsf{Div}X^{(\!\!R\!)}$  support, you are able to enjoy  $\mathsf{Div}X$  encoded videos and movies from the

Internet, including purchased Hollywood films. The DivX media format is an MPEG-4 based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW and DVD recordable discs, USB storage and other memory cards for playback on your DivX Certified<sup>®</sup> Philips device.

#### **USB** connection



Simply plug in your portable USB device to the USB connector on your Philips portable DVD player and playback your digital videos, music or photos directly. Now you can share your favorite moments with family and friends.

#### Spill resistant design

The device is built to resist accidental spillages. The spill-proof design with its rubber surface prevents liquids from damaging electrical or mechanical components, and it is easy to clean.



# Specifications

### **Product dimensions**

- Product dimensions (W x H x D):
- 20,2 x 4 x 16,4 cm • Weight: 0,82 kg

## **Picture/Display**

- Diagonal screen size: 7 inch / 18 cm
- Resolution: 480(w)x234(H)x3(RGB)
- Display screen type: LCD TFT

#### Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 5mW RMS(earphone)
- Signal to noise ratio: >80dB(line out),
- >76dB(earphone), >62dB(built-in speakers)

#### Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- Disc Playback Modes: Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Zoom, Resume Playback from Stop
- Video disc playback system: PAL, NTSC
- Compression formats: Divx, MPEG4

### **Audio Playback**

- MP3 bit rates: 32 320 kbps
- Compression format: Dolby Digital, MP3
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Jolliet

# Connectivity

- DC in: 9V, 0.8A
- Headphone jack: 3.5mm Stereo Headphone

# • USB

#### Convenience

- Battery charging indication
- Shock proof
- Waterproof standard: IPX4

#### Accessories

- AC/DC Adaptor: DC 9V, 0.8A, 110-240v, 50/60Hz
- User Manual: Multi-languages
- Car kit: cigarette outlet adaptor, 12vDC

#### Power

- Battery Type: Built-in battery
- Battery lifetime: Up to 3hrs\*

#### Packaging dimensions

- Packaging dimensions (W x H x D):
- 26,2 x 24,2 x 7,4 cm
- Nett weight: 1,06 kg
- Gross weight: 1,31 kg
- Tare weight: 0,25 kg
- EAN: 87 12581 68124 1
- Number of products included: 1
- Packaging type: Dummy • Type of shelf placement: Dummy

# **Outer Carton**

- Outer carton (L x W x H):  $28 \times 24,5 \times 26$  cm
- Nett weight: 3,18 kg
- · Gross weight: 4,27 kg
- Tare weight: 1,09 kg
- GTIN: 1 87 12581 68124 8
- Number of consumer packagings: 3



Issue date 2017-04-05

12 NC: 8670 001 01194

EAN: 87 12581 68124 1

© 2017 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.5

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com

\* DivX. DivX Certified, and associated logos are trademarks of

- DivXNetworks, Inc. and are used under license. Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of
- charge cycles vary by use and settings. \* Battery life varies by use and settings. \* Battery life of playtime is approximate and may vary depending on application condition. To optimize battery life, user should turn LCD backlight to minimum, connect to headphones (not built-in speakers) and listen at medium volume level, and use the product at room temperature.
- \* Dolby and the double-D symbol are registered trademarks of Dolby Laboratories Inc.