

Philips  
Micro Hi-Fi System

- USB

MCM280D



## Unleash your music in superb sound

from iPhone, iPod, USB, CD and radio

Enjoy your iPhone/iPod music in superb sound with the Philips Micro Hi-Fi system MCM280D. Stylishly designed, it also charges your iPhone/iPod while it plays, rips CDs to MP3 and plays MP3/WMA music from portable devices via USB Direct.

### Unlimited listening pleasure

- Play and charge your iPod/iPhone simultaneously
- Rip your favourite CDs to MP3
- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback

### Enrich your sound experience

- All-in-one remote control for your system and iPod/iPhone
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 60 W RMS total output power

### Design that blends into your interior

- Front motorised CD door with viewing window
- Stylishly sleek and compact design



asimpleswitch.com



asimpleswitch.com

# PHILIPS

# Highlights

## Play and charge your iPod/iPhone

Enjoy your favourite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

## Rip your favourite CDs to MP3

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favourite music from CDs to your USB device or MP3 player — with one

touch and no computer needed you can create your own MP3 files via direct MP3 digital recording.

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most

important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.



# Specifications

## Sound

- Output power (RMS): 2 x 30W
- Output Power: 2 x 60 W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable
- Loader Type: Front, Motorised
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store
- RDS: Programme Type, Station Name, Radio Text, RDS Clock Set, News

## Connectivity

- Aux in: (MP3 Link)
- Headphones: 3.5 mm
- Other connections: FM Antenna
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm, iPod Alarm, Sleep timer
- Clock: On main display

- Display Type: LCD
- Backlight colour: Blue
- Eco Power Standby: 1 watt

## Accessories

- Included accessories: AC Power Cord, Guarantee booklet, Stand, FM antenna
- Remote control: 40-key with Lithium batteries
- AC/DC Adapter: Switching power supply
- Quick start guide: English
- User Manual: English
- Cradle: For iPhone/iPod

## Dimensions

- Set dimensions (W x H x D): 211 x 250 x 160 mm
- Main speaker dimensions (W x H x D): 158 x 250 x 193 mm
- Packaging dimensions (W x H x D): 397 x 339 x 311 mm
- Weight incl. Packaging: 6 kg

## Audio Recording

- Recording Media: USB device
- USB recording modes: Instant record, Programmed tracks, Single disc, Single track
- USB recording sources: CD

## Power

- Power supply: 100-240 VAC, 50/60 Hz

## iPhone compatibility

- Compatible with: iPhone, iPhone 3G

## iPod compatibility

- Compatible with: iPod, iPod 5th Generation, iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod touch, iPod touch 2nd Generation, iPod with colour display



Issue date 2013-05-10

Version: 1.0.2

12 NC: 8670 000 55244  
EAN: 87 12581 49603 6

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)