

PHILIPS



True Wireless Headphones

Clear call quality

6 mm drivers for powerful bass

Ergonomic design for comfort

IPX4 splash/sweat resistant



TAT1108BK

Hear your sounds clearly

Hear tunes and calls properly. These True Wireless headphones use 6 mm drivers for rich sound and powerful bass, and an AI mic for clear calls. IPX4 splash and sweat resistance, and a pocket-sized charging case for 15 hours of play time.

Style and comfort

- Secure, comfortable in-ear fit
- Short hockey stick design

Active all day

- IPX4 splash and sweat resistant
- No worries. Up to 15 hours of play time with the case

Powerful playlists. Clear calls

- Custom 6 mm drivers for great sound and powerful bass
- AI mic for clear call quality

Specifications

Sound

Frequency range: 20–20,000 Hz

Speaker diameter: 6 mm

Impedance: 16 Ohm

Maximum power input: 5 mW

Sensitivity: 106 dB (1k Hz)

Driver type: Dynamic

Connectivity

Bluetooth version: 5.3

Wireless

Bluetooth profiles: A2DP, AVRCP, HFP

Maximum range: Up to 10 m

Supported codec: SBC

Type of wireless transmission: Bluetooth

Outer Carton

Length: 26.5 cm

Number of consumer packages: 24

Width: 22.2 cm

Gross weight: 2.972 kg

Height: 24.5 cm

GTIN: 1 48 95229 13175 7

Net weight: 1.512 kg

Tare weight: 1.46 kg

Convenience

Water resistance: IPX4

Mono mode for TWS

Type of controls: Button

Inner Carton

Length: 12 cm

Number of consumer packages: 3

Width: 10.5 cm

Height: 11.8 cm

Net weight: 0.189 kg

Gross weight: 0.332 kg

Tare weight: 0.143 kg

GTIN: 2 48 95229 13175 4

Power

Rechargeable

Number of batteries: 3 pcs

Music play time: 5 + 10 hour(s)

Talk time: 5 hr

Charging time: 2 hour(s)

Battery type (Charging case): Lithium Polymer (built-in)

Battery type (Earbud): Lithium Polymer (built-in)

Battery weight (Total): 6.1 g

Battery capacity (Case): 250 mAh

Battery capacity (Earbud): 35 mAh

Packaging dimensions

Height: 11.8 cm

Packaging type: Carton

Type of shelf placement: Hanging

Width: 9.5 cm

Depth: 3.7 cm

Number of products included: 1

EAN: 48 95229 13175 0

Gross weight: 0.098 kg

Net weight: 0.063 kg

Tare weight: 0.035 kg

Accessories

Quick Start Guide

Eartips: 3 pairs (S/M/L)

Charging case

Charging cable: USB-C cable, 200 mm

Design

Colour: Black

Ear coupling material: Silicone

Ear fitting: In-ear

In-ear fitting type: Silicone ear-tip

Telecommunication

Microphone for call: an AI mic

Dimensions

Charging case dimension (W x D x H): 3.11 x 5.95 x 3.20 cm

Earbud dimension (W x D x H): 2.03 x 2.97 x 2.49 cm

Total weight: 0.036 kg

UPC

UPC: 8 40063 20313 6

Voice assistant

Voice assistant compatible: Apple Siri, Google

Assistant

Voice assistant activation: Manual

Voice assistant support

Highlights

15 hours of play time

No matter how long your day is, these headphones have got you covered. You get 5 hours of play time and an extra 10 hours from the handy, pocket-sized charging case.

6 mm dynamic drivers

Hear your sounds the way they were meant to be heard. These headphones use custom-designed 6 mm dynamic drivers to bring you a real listening experience. The drivers' large power capacity enhances the dynamics and bass so you'll never miss a beat.

Clear call quality

Don't let sounds from the world interrupt your listening. These headphones feature an AI microphone that uses an advanced AI algorithm to filter out the noise you don't want to hear and ensure clear call quality. Hear each other clearly every time.

IPX4 splash/sweat resistant

An IPX4 rating and powerful 6 mm drivers let you enjoy great sound in any weather! The headphones are splash resistant and won't mind a little rain or sweat, so you don't need to worry about getting caught in a shower.

Secure, comfortable in-ear fit

These comfortable earbuds fit securely into your ear canals, creating a perfect seal that diminishes external noise. Hear every beat and word! Enjoy real comfort with three sizes of soft, interchangeable silicone ear-tip covers.

