

Philips  
Micro Hi-Fi System

Made for iPod

MP3/WMA-CD playback

MCM239D



## Rich sound in compact design

Play and charge your iPod

Free your iPod music and enjoy it in superb sound! The compact MCM239D delivers dynamic sound performance and the essential functionalities that will let you enjoy music just the way you like it.

### Enrich your sound experience

- Play and charge your iPod
- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Convenient line-in jack for portable music playback
- 2 x 5 W RMS total output power

### Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 40 pre-set stations for extra convenience

### Fits any space, any lifestyle

- Compact design
- Easy-to-use remote control included

**PHILIPS**  
sense and simplicity

# Highlights

## Play and charge your iPod



Enjoy your favourite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favourite music in superb quality. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and play back the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

## USB Direct-MP3/WMA



With the USB Direct mode, you can simply select the music on a USB device and play back all your content. All you have to do is plug in your USB device to play back music or export content from the device.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses

graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output power (RMS): 2 x 5 W
- Output Power: 2 x 10 Watts music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer, Full range

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable
- Loader Type: Front
- Cradle playback mode: Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause, Menu, Up and Down
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store
- RDS: Programme Type, Station Name, Radio Text, RDS Clock Set

## Connectivity

- Aux in: Line in
- Headphones: 3.5 mm

- Other connections: FM Antenna, Cradle connection, MW Antenna
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Display Type: LCD
- Backlight colour: Blue
- Eco Power Standby: 1 watt

## Accessories

- Included Accessories: FM/MW Antenna, Stand
- Remote control: 24-key with Lithium batteries
- AC/DC Adapter: Switching power supply
- Docking Station: iPod wired dock
- Quick start guide: English
- User Manual: English

## Dimensions

- Set dimensions (W x H x D): 211 x 250 x 160 mm
- Main speaker dimensions (W x H x D): 158 x 250 x 118 mm
- Packaging dimensions (W x H x D): 350 x 310 x 305 mm
- Weight incl. Packaging: 6.0 kg

## iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with colour display, iPod 5th Generation

## Power

- Power supply: 100-240 VAC, 50/60 Hz



Issue date 2009-08-13

Version: 1.0.3

12 NC: 8670 000 33273  
EAN: 87 12581 35608 8

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)