



Philips  
Bluetooth® mono headset

Earbud  
Black

SHB1100



## Comfortable and hands free safe talk

comfortable with Light and Small design for long hour talk

### **Wear it comfortably for hours!**

- Ergonomic earhook

### **Make sure you are clearly understood**

- Clear, echo free calls

### **Talk freely - handsfree and wireless**

- Bluetooth enabled wireless handsfree talking
- Wireless call management

### **Universal: Works with your Bluetooth enabled phone**

- Bluetooth HSP/HFP compliant - Universal

# PHILIPS

# Specifications

## Connectivity

- Bluetooth profiles: handsfree, headset
- Bluetooth version: 3.0+EDR
- Maximum range: up to 33 feet / 10

## Convenience

- Call management: Answer / End call, Reject call, Last number redial, Call transfer

## Power

- Talk time: up to 5 hour(s)
- Battery Type: Li-polymer
- Rechargeable
- Power supply headset: via USB adapter
- Standby time: up to 120 hour(s)

## Accessories

- Included: Earhook (optional), Quick start guide, USB charging cable

## Inner Carton

- Gross weight: 0.437 kg
- Inner carton (L x W x H): 18 x 16.5 x 8 cm
- Nett weight: 0.192 kg
- Number of consumer packagings: 6

- Tare weight: 0.245 kg
- GTIN: 2 04 89518 56023 9

## Outer Carton

- Gross weight: 2.994 kg
- Outer carton (L x W x H): 53 x 19.5 x 19 cm
- Nett weight: 1.152 kg
- Number of consumer packagings: 36
- Tare weight: 1.842 kg
- GTIN: 1 04 89518 56023 2

## Packaging dimensions

- Packaging dimensions (W x H x D): 5.1 x 17.5 x 3.1 cm
- Gross weight: 0.06 kg
- Nett weight: 0.032 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 0.028 kg
- Type of shelf placement: Both
- UPC: 4 89518 56023 5

## Product dimensions

- Product dimensions (W x H x D): 1.6 x 3.6 x 2.2 cm
- Weight: 0.015 kg

# Highlights

## Clear, echo free calls

Enjoy clear, echo free calls with the headsets' highly sensitive microphone and smart acoustic design.

## Wireless handsfree talking

Using your cellphone without a headset can be inconvenient and unsafe. In many locations it is also illegal while driving. Wired handsfree kits add the hassle of a cable. A Bluetooth headset replaces the cable with a short range wireless Bluetooth connection, so your hands are free and your freedom to move is not hampered by a cable. Because the transmitted energy close to your head is much lower than that radiated from your mobile phone Bluetooth also decreases potential risks associated with cellphone radiation.

## Wireless call management

Manage your call without using your mobile phone. This includes call acceptance, rejection, voice dial and redial. Voice dial and redial have to be supported by your mobile phone.

## Bluetooth HSP/HFP compliant

Bluetooth is a cable replacement technology. Bluetooth is a global standard, so Bluetooth devices of different manufacturers can interoperate using shared Bluetooth profiles. HSP (Handset Profile) and HFP (Handsfree Profile) are the profiles required for typical Bluetooth headset operations. If your mobile phone is compliant to HSP or HFP (like virtually any Bluetooth enabled phone) this headset will work with it. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Koninklijke Philips Electronics N.V. is under license.

## Ergonomic earhook

The ergonomic earhooks size can be adapted in various steps to fit your ears, which will not only increase comfort but also ensure a safe fixture. In addition the earhook can be adapted to accommodate both left- and right-ear wearing styles.



Issue date 2017-06-20

Version: 3.0.5

12 NC: 8670 001 16486  
UPC: 4 89518 56023 5

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)