



Philips
Bluetooth® mono headset

Mono BT Headset
On-ear

SHB1101

Comfortable and hands free safe talk

Frequency: 2.4GHz, Class 2

Comfortable with Light and Small design for 6 hours talking time. Stand-by time 110 hours.

Wear it comfortably for hours!

- Ergonomic earhook

Make sure you are clearly understood

- Clear, echo free calls

Talk freely - handsfree and wireless

- Bluetooth enabled wireless handsfree talking
- Wireless call management

Universal: Works with your Bluetooth enabled phone

- Bluetooth HSP/HFP compliant - Universal

PHILIPS

Specifications

Connectivity

- Bluetooth profiles: handsfree, headset
- Bluetooth version: 3.0+EDR
- Maximum range: up to 33 feet / 10

Convenience

- Call management: Answer / End call, Reject call, Last number redial, Call transfer

Power

- Talk time: up to 6 hour(s)
- Battery Type: Li-polymer
- Rechargeable
- Power supply headset: via USB adapter
- Standby time: up to 110 hour(s)

Packaging dimensions

- EAN: 48 95229 11220 9
- Number of products included: 1

- Packaging type: Carton
- Type of shelf placement: Laying

Inner Carton

- GTIN: 2 48 95229 11220 3
- Number of consumer packagings: 6

Outer Carton

- GTIN: 1 48 95229 11220 6
- Number of consumer packagings: 36

Product dimensions

- Product dimensions (W x H x D):
1.1 x 0.6 x 2.1 cm

Accessories

- Included: Earhook (optional), Quick start guide, USB charging cable

Highlights

Clear, echo free calls

Enjoy clear, echo free calls with the headsets' highly sensitive microphone and smart acoustic design.

Wireless handsfree talking

Using your cellphone without a headset can be inconvenient and unsafe. In many locations it is also illegal while driving. Wired handsfree kits add the hassle of a cable. A Bluetooth headset replaces the cable with a short range wireless Bluetooth connection, so your hands are free and your freedom to move is not hampered by a cable. Because the transmitted energy close to your head is much lower than that radiated from your mobile phone Bluetooth also decreases potential risks associated with cellphone radiation.

Wireless call management

Manage your call without using your mobile phone. This includes call acceptance, rejection, voice dial and redial. Voice dial and redial have to be supported by your mobile phone.

Bluetooth HSP/HFP compliant

Bluetooth is a cable replacement technology. Bluetooth is a global standard, so Bluetooth devices of different manufacturers can interoperate using shared Bluetooth profiles. HSP (Handset Profile) and HFP (Handsfree Profile) are the profiles required for typical Bluetooth headset operations. If your mobile phone is compliant to HSP or HFP (like virtually any Bluetooth enabled phone) this headset will work with it. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Koninklijke Philips Electronics N.V. is under license.

Ergonomic earhook

The ergonomic earhooks size can be adapted in various steps to fit your ears, which will not only increase comfort but also ensure a safe fixture. In addition the earhook can be adapted to accommodate both left- and right-ear wearing styles.



Issue date 2022-05-12

Version: 1.0.1

12 NC: 8670 001 70364
EAN: 48 95229 11220 9

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com