

Philips Fidelio docking speaker





SBD7500





Obsessed with sound

Designed to go places

Compact and extremely portable, this player is no lightweight when it comes to performance. Designed to travel, it delivers sound from your iPhone/iPod that is surprisingly powerful - letting you enjoy great music wherever life takes you.

Sound that blows you away

- wOOx technology for rich yet precise bass without distortion
- DBB to preserve low tones for deep bass at any volume level
- Shielding technology to block mobile phone interference

Made to go places

• Elegant, slim and compact design to fit into any briefcase

Truly portable and versatile

- Battery or AC power option for music enjoyment anywhere
- Dock any iPod/iPhone, even in its case
- · AUX-in for easy connection to almost any electronic device
- Discover, share music and more features via DockStudio app





Specifications

Sound

- Sound enhancement: Dynamic Bass Boost, wOOx™ Technology
- Sound system: stereo
- Volume control: up/down
- Output power: 10 W RMS

Loudspeakers

• Speaker drivers: Neodymium magnet system

Connectivity

• Aux in

Accessories

Cables/Connection: AC-DC adapter, MP3 Link cable

Convenience

· Charging device: iPhone, iPod







Power

- Power supply: battery, 100 240 V AC, 50/60 Hz
- Battery type: AA size (LR6)
- Number of batteries: 4
- Battery lifetime: 8 hr

iPod compatibility

 Compatible with: iPod, iPod mini, iPod with colour display, iPod classic, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod touch, iPod nano 4th generation, iPod touch 2nd generation, iPod nano 5th generation, iPod touch 2nd gen 8/16/32 GB, iPod 5th generation

iPhone compatibility

• Compatible with: iPhone, iPhone 3G, iPhone 3GS

Highlights

wOOx technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Dynamic Bass Boost (DBB)



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

DockStudio app on App Store



The free Philips DockStudio app brings lots of cool exclusive features to your docking speaker. You can listen to your favourite radio shows, discover new music with thousands of Internet radio stations worldwide, browse through your music collection and share what you're listening to with friends via Facebook and Twitter. In Clock mode, it lets you set multiple customised music alarms and gives updated weather reports. Download it from App Store and find out more.



Issue date 2013-05-10

Version: 7.0.12

12 NC: 8670 000 56966 EAN: 87 12581 50984 2 Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com