



Philips
PhotoFrame

20.3 cm/8" LCD

4:3 frame ratio

8FF3FPW

Share your memories

How many digital pictures are hidden on your PC? See, share, organise and relive your memories with Philips PhotoFrame™, the easiest way to share your memories by displaying your digital photos in stunning quality - without a PC.

Top-quality display for print-like pictures

- High pixel density for sharp and detailed photo display
- imagen for sharp and vibrant colour
- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor

Easily display and manage your digital photos

- Have fun with collages: display multiple photos in one view
- View USB flash drive photos without a PC

Simple intuitive operation and great convenience

- Auto photo orientation to fit portrait or landscape modes

Green design

- Auto on/off display at pre-set times for power saving

Stylish curved design complements your photos

- Tasteful glossy finish and great feel

PHILIPS
sense and simplicity

Highlights

High Pixel Density Display

The very best high-density screen shows off your treasured photos with the same 'real life' rich detail and vibrant colours as high-quality prints.

imagen technology

imagen is exclusive Philips photo enhancement technology that automatically analyses your photos to correct colour and adjust for optimal contrast: imagen separates colours to avoid "crosstalk", adjusts brightness distribution for great visual contrast and corrects Gamma for colour accuracy.

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo is displayed in 4:3 ratio for the best viewing experience.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form, which automatically and randomly compiles different photos together, eliminating unattractive borders that may result from photos that are smaller than the screen size.

Viewing photos in USB flash

A USB connector for easy viewing and sharing of photos stored on a USB flash drive.

Auto on/off display

A timer turns PhotoFrame on and off at the times you choose, reducing energy consumption for the sake of our environment and saving up to one third of your PhotoFrame energy costs.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognises PhotoFrame orientation and displays each photo in its proper mode.



High pixel density



SmartContrast



MEMORY CARD SLOT



Imagen



Collage



RadiantColor



SmartPower



USBConnectivity

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 130° (H)/110° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 4:3
- Brightness: 250 cd/m²
- Panel resolution: 800 x 600
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo

Convenience

- Card Reader: Built in (2 x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 20 Megapixels
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom and crop
- Photo effects: Black and White, Frames, Sepia, Radiant colour
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Grey, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Alarm
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory

- Plug and Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese, Japanese

Accessories

- Included accessories: AC-DC Adapter, USB cable, Stand, Quick start guide, User Manual

Dimensions

- Set dimensions with stand (W x H x D): 244.6 x 167.4 x 121.1 mm
- Weight: 0.494 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power consumption: 6.3 W
- Power mode supported: AC powered

Packaging dimensions

- Packaging dimensions (W x H x D): 29.3 x 27.9 x 8.5 cm
- Net weight: 0.84 kg
- Gross weight: 1.099 kg
- Tare weight: 0.259 kg
- EAN: 87 12581 41222 7
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 31.2 x 29.6 x 20.2 cm
- Net weight: 1.68 kg
- Gross weight: 2.736 kg
- Tare weight: 1.056 kg
- GTIN: 1 87 12581 41222 4
- Number of consumer packages: 2



Issue date 2011-07-13

Version: 5.0.14

12 NC: 8670 000 38997
EAN: 87 12581 41222 7

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com