



Philips  
Filter hand shower

### ACF shower filter

Pressure-increasing design  
Three spray modes  
Easy clean silicone nozzle

ASH1516CH/10

## Enjoy a clean bath and a lively life

With an ACF filter, take a fresh shower

With an ACF shower filter, this hand shower can remove residual chlorine. And it has a pressure-increasing design and three kinds of water spray, delivering a clean and comfortable shower experience for you.

#### ACF shower filter

- With ACF filter

#### Convenient filter replacement

- Convenient filter replacement

#### The three kinds of water spray meet different usin

- Silk spray for comfortable facial massage
- Mixed spray for soft rinsing of the whole body
- Pressurised spray for refreshing tired skin

#### Easy to remove limescale with liquid silicone nozzle

- Easy to remove limescale with liquid silicone nozzle

#### Pressure-increasing design

- Microporous pressurisation

# PHILIPS

Filter hand shower  
ACF shower filter Pressure-increasing design, Three spray modes, Easy clean silicone nozzle

ASH1516CH/10

# Specifications

## General specifications

- Type: Filter type
- Colour: Chrome
- Finishing: Electroplating
- Shower head size: Ø120mm
- Inlet water pressure: 0.05-0.5 MPa
- Spray type: Pressurised/Silk/Mixed
- Switching mode: Lever
- Connection type: G1/2

## Filter specification

- Filter model: ASH138/10

- Main filter element: ACF filter
- Lifespan: 1 month

## Country of origin

- System: China
- Country of origin: China
- Filter: China

## Service

- Warranty period: 2 year(s)

# Highlights

## Silk spray

Silk spray can release a radial dense spray to cover the face in multiple directions, it's ideal for facial massage.

## Mixed spray

Combination of pressurised spray and silk spray for realizing full coverage spray, it's suitable for soft rinsing of whole body.

## Pressurised spray

116 microhole nozzles achieve pressurized spray, solve difficulties under low water pressure environments, and the high dense spray brings full relaxation to the skin.

## ACF shower filter

ACF (activated carbon fibre) is an adsorption material made by carbonisation, compared with traditional activated carbon, it has no rough hole, the activated carbon fibre is full of micropores with high specific surface area, its adsorption capacity is much better than that of granular activated carbon. Effectively remove residual chlorine, silt, rust, other large particles and odour.

## Easy clean silicone nozzle

The nozzles are made of liquid silicone. The high-quality, tear-resistant liquid silicone is easy to rub by your fingers. You only need to rub the nozzles gently to remove the limescale.

## Pressure-increasing design

The spray head has 116 microhole nozzles with a diameter of 0.45 mm, which makes the water pressure increase and offers you a completely indulgent showering experience even in the low water pressure areas or in water consumption peak periods.

## Convenient filter replacement

Easy rotation 90° can be disassembled, without multi-layer threads, shower with assembly in place and disassembly marks, so that family members can easily disassemble.



Issue date 2023-11-24

Version: 1.1.1

EAN: 48 95244 61088 9

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)