

Philips
DVD player

DivX playback

DVP3148K



Movies from PC on your TV

With Karaoke

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

Bring audio and video to life

- 12-bit/108MHz video processing for sharp and natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- High quality outputs for analog and digital audio
- Progressive Scan component video for optimized image quality
- 5.1 channel audio output for surround sound

Play all your movies and music

- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays DivX, MP3, WMA and JPEG digital camera photos
- DivX Certified for standard playback of DivX videos

Fits any space, any lifestyle

- Ultra-slim design that fits anywhere

Enjoy enhanced karaoke

- Karaoke Scoring for fun and exciting song contests at home

PHILIPS

DVD player
DivX playback

DVP3148K/51

Highlights

192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Karaoke Scoring

Add a dash of fun to your Karaoke sessions with Karaoke Scoring. Allow your performance to be judged for further improvement, or for friendly competitions.

Karaoke Scoring automatically rates your singing and gives you a humorous picture that is tied to how well you did. The fun never ends.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum

resolution. At such a speed, your eye perceives a sharper picture with no line structure.

5.1 channel audio output

5.1 channel audio output for surround sound

Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.



Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD+R/+RW, DVD-R/-RW, DivX, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- MP3 bit rates: 32 - 320 kbps
- Compression format: PCM, MP3, Dolby Digital, WMA

Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Slideshow, Zoom

Multimedia Applications

- Playback Formats: DivX, JPEG Still pictures, MP3

Connectivity

- Front / Side connections: Microphone
- Rear Connections: Composite video (CVBS) output, Digital coaxial out, Component Video out Progressive, Analog audio Multi-channel out

Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Polish, Russian
- Karaoke: MIC volume

Power

- Power consumption: < 10 W
- Standby power consumption: < 0.8 W
- Power supply: 230V, 50Hz

Accessories

- Included accessories: Audio/Video cable, World Wide Warranty leaflet, Remote Control, 2 x AAA Batteries, User Manual

Dimensions

- Set dimensions (W x H x D): 360 x 37 x 209 mm
- Packaging dimensions (W x H x D): 415 x 82 x 282 mm



Issue date 2014-02-10

Version: 1.0.9

12 NC: 8670 000 30082
EAN: 87 12581 33550 2

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com