



Philips  
Portable DVD Player with  
Zero Bright Dot™ screen

21.6cm (8.5") widescreen LCD  
digital TV

**PET835**



## Slim set with DVD slot

with built-in digital TV receiver

The magic of movies and music comes to life on the tablet-style Philips PET835 with 8.5" LCD display. Enjoy free-to-air digital TV programs with the built-in digital TV receiver. Comes with Smart Car Mount and USB connector.

### Immerse in AV entertainment on the go

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® & MPEG4 movies
- Play MP3/WMA-CD, CD and CD-RW
- Share JPEG image files with Picture CD

### Experience the digital interactive TV phenomenon

- Support DVB-T for free-to-air digital TV and radio channels
- 7-day Electronic Program Guide (EPG)
- Direct Teletext and subtitle function support

### Optimized viewing anywhere

- Zero Bright Dot™ screen for optimal screen quality
- 21.6 cm/8.5" TFT color LCD display for high quality viewing

### For ultimate convenience

- Enjoy up to 3 hours playback with a built-in battery\*
- Smart Car Mount for ease-of-use
- USB connection for video, photo and music playback

# PHILIPS

# Highlights

## Play DVD, DivX and MPEG4

With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX® CDs can be played back on selected DVD players, DVD Recorders and Home Theater Systems.

## Support DVB-T

Expand your entertainment experience and enjoy digital channel programs - for free. With DVB-T (Digital Video Broadcasting - Terrestrial), you can receive free digital TV and

radio programs in Europe. The signal is kept digital without any analog steps in between, to preserve the highest quality.

## Zero Bright Dot™ screen

Enjoy highest-quality images that are free from annoying blank spots on the LCD screen. LCD displays commonly have imperfections, termed as 'bright dots' by the LCD industry. A limited number of bright dots were once considered an inevitable side effect of LCD mass production. With Philips' strict quality control procedures used in our Portable DVD Players, our LCD displays are produced with zero tolerance for bright dots. Select Portable DVD Players come with Philips Zero Bright Dot™ Policy to guarantee optimal screen quality.

## Smart Car Mount

To enjoy entertainment on the go, why not bring your portable DVD player from home on the road with you? A unique Car Mount system ensures ease-of-use, with a quick-release arm that facilitates easy removal of the player when not in use. You can bring the portable DVD player with you, leaving just the Mount behind in the car.

## USB connection

Simply plug in your portable USB device to the USB connector on your Philips portable DVD player and playback your digital videos, music or photos directly. Now you can share your favorite moments with family and friends.



# Specifications

## Picture/Display

- Display screen type: LCD TFT
- Diagonal screen size (inch): 8.5 inch
- Resolution: 480(W)x234(H)x3(RGB)
- Brightness: 200 cd/m<sup>2</sup>
- LCD panel type: Anti-glare polarizer
- Contrast ratio (typical): 250:1
- Effective viewing area: 187.2x105.3
- Pixel pitch: 0.13(W) x 0.45(H)
- Response time (typical): 30 ms

## Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >76dB(line out), >62dB(built-in speakers)

## Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, WMA, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: MPEG4, Divx

## Audio Playback

- Compression format: Dolby Digital, MP3, WMA
- MP3 bit rates: 32 - 320 kbps
- WMA bit rates: 32 - 192 kbps
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- File systems supported: ISO-9660, Joliet

## Connectivity

- DC in: 9V

- AV output: Composite (CVBS) x1
- Headphone jack: 3.5mm Stereo Headphone x 2
- AV input: Composite (CVBS) x1
- Audio Output - Digital: Coaxial (cinch)

## Convenience

- Battery charging indication
- Shock proof

## Tuner/Reception/Transmission

- Digital TV: DVB Terrestrial \*

## Video Decoding

- Aspect Ratio: 16:9, 4:3, 4:3 Letterbox
- Reception-Demodulation: COFDM 2K/8K, MPEG-2 DVB compliant, Network: MFN/SFN, QPSK

## Accessories

- AC/DC Adaptor: DC-in 9V; 100-240v, 50/60Hz
- Cables: 1 x AV Cables
- Car kit: cigarette outlet adaptor, 12vDC
- Remote control: AY5506 slim remote
- User Manual: 16 languages
- Smart car mount: 1 pcs
- Pouch: Protective pouch
- Included accessories: Aerial antenna

## Dimensions

- Product dimensions (W x H x D): 255 x 170 x 31 mm
- Product weight: 1 kg
- Packaging dimensions (W x H x D): 310 x 200 x 145 mm
- Master carton quantity: 3
- Master carton dimensions: 333 x 236 x 458 mm
- Master carton weight: 7.58 kg
- Packaging type: D-box



Issue date 2014-02-07

Version: 2.1.7

12 NC: 8670 000 28755  
EAN: 87 12581 33870 1

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)