

Philips
Micro Hi-Fi System



MCM330

Immerse yourself in dynamic sound

with Living Sound

Trendy and progressive, unique innovation and style appeals to you. And so will the vividly chic MCM330 with dynamic sound performance packed in a sleek design with Living Sound that surrounds you.

Multiple sources for more choices

- MP3 Link for portable music playback
- Play MP3/WMA-CD, CD and CD-RW
- USB Direct and SD/MMC card slots for MP3/WMA music playback
- Digital tuning with presets

Enrich your sound experience

- LivingSound for wider, immersive stereo sound
- wOOx loudspeaker technology for deep and powerful bass
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2 x 10 W RMS/2 x 20 W music power

Design that blends into your interior

- Elegant design with motorised sliding front door
- Super sleek and flexible wall-mountable design

PHILIPS

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

LivingSound

Philips' patent-pending LivingSound vastly expands the sweet spot (the ideal listening location in your room) so you can enjoy truly immersive music over a wider area. Combining various sound processes, LivingSound recovers the richness and spatial details of the soundstage that are often lost with a compact stereo system. The effect is a larger than expected sweet spot - one that is extensively and evenly distributed around the room. Now your music enjoyment is no longer confined to the traditionally narrow area. Enjoy optimum stereo sound in a wider area.

wOOx™ Technology

wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise

base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

MP3 Link for portable music

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

USB/SD/MMC music playback

Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct and SD/MMC card slots. Simply plug your device into the USB port, or insert your memory card in the SD/MMC card slot on your Philips music system, your digital music and photos will be played directly from the device. Now you can share your favourite moments with family and friends!



Specifications

Sound

- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, wOOx technology
- Output Power: 2 x 10 W RMS/2 x 20 W music power
- Type: LivingSound
- Volume Control: Volume Control up/down

Loudspeakers

- Built-in speakers: 4

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, SD/MMC card, USB flash drive
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable, Fast Forward/Reverse, Next/Previous Track Search
- Loader Type: Front, Motorised
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store
- RDS: Programme Type, Station Name, Radio Text, RDS Clock Set
- Station presets: 20

Connectivity

- Headphones: 3.5 mm
- Other connections: FM fixed pigtail antenna
- USB: USB host
- 3.5 mm stereo line in: MP3 Link

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Display Type: VFD display
- Eco Power Standby: 1 watt
- Wall mountable/Ceiling Throw: Wall mountable
- Indications: DIM mode

Accessories

- Included accessories: AC-DC Adapter
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- Remote control: 40-key remote with lithium battery
- User Manual: 16 languages
- Cables: MP3 line-in cable

Dimensions

- Packaging dimensions (W x H x D): 622 x 156 x 170 mm
- Set dimensions (W x H x D): 571 x 143 x 91 mm
- Weight incl. Packaging: 3.07 kg

Power

- Power supply: 100-240 VAC, 50/60 Hz



Issue date 2013-05-13

Version: 2.0.8

12 NC: 8670 000 49678
EAN: 87 12581 46502 5

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Avoid extensive use of the set at a volume higher than 85 decibels because this may damage your hearing.