Register your product and get support at www.philips.com/welcome

DS3800W/10



EN User manual



Contents

1	Important Safety Notice	4 4 5
2	Your Entertainment System Introduction What's in the box What else you need Overview of the main unit Get started to use AirPlay	7 7 7 8 9
3	Prepare Connect power Turn DS3800W on	10 10 10
4	Connect to your home Wi-Fi network for AirPlay Scenario 1: Connect to a WPS router Scenario 2: Connect to a non-WPS router	11 11 12
5	Play Stream audio from your iTunes music library to DS3800W Control play Use advanced sound settings Play/charge your iPod/iPhone/iPad through USB socket Play from an external device	18 19 19 20 20
6	Update firmware Download the update file Update from the configuration page	22 22 22
7	Product information Specifications	24 24
8	Troubleshooting	25

1 Important

Safety

Information for Europe: Know these safety symbols





The 'exclamation mark' calls attention to features for which you should carefully read the supplied literature to prevent operating and maintenance problems.

The 'lightening bolt' symbol indicates uninsulated components within the product that can cause an electric shock.


To reduce the risk of fire or electric shock, do not expose the product to rain or moisture and do not place any objects filled with liquids, such as vases, on the product.

- 1 Read these instructions.
- (2) Keep these instructions.
- (3) Heed all warnings.
- (4) Follow all instructions.
- 5 Do not use this product near water.
- 6 Clean only with dry cloth.
- (7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not remove the casing of this product.

- (9) Do not expose the product to dripping / splashing water, rain or high humidity.
- (10) Keep this product away from direct sunlight, naked flames or heat.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other electrical equipment (including amplifiers).
- (12) Do not place any other electrical equipment on the product.
- (13) Do not place any sources of danger on the product (e.g. objects containing liquids, burning candles).
- This product may include batteries. Please refer to safety and disposal instructions for batteries in this user manual.
- (15) Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

Warning

- Never remove the casing of this apparatus.
- Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.
- Keep this apparatus away from direct sunlight, naked flames or heat.
- Ensure that you always have easy access to the power cord, plug or adaptor to disconnect this apparatus from the power.



Warning

• To avoid injuries, never put your fingers into the bass pipe (1) or your hands into the aluminum ring (2).

Risk of overheating! Never install this apparatus in a confined space. Always leave a space of at least four inches around this apparatus for ventilation. Ensure curtains or other objects never cover the ventilation slots on this apparatus.

Mains fuse

This information applies only to products with a UK mains plug.

This product is fitted with an approved molded plug. If you replace the fuse, use one with:

- the ratings shown on the plug,
- a BS 1362 approval, and
- the ASTA approval mark.

Contact your dealer if you are not sure about what type of fuse to use.

Caution:To conform with the EMC directive (2004/108/EC), do not detach the plug from the power cord.

Notice

()

This product complies with the radio interference requirements of the European Community.

(()5	6()(R&1	TE	Dire	ecti	ve I	999	/5/E	С
BG	\checkmark	RO	\checkmark	BE	\checkmark	LT	\checkmark	LI	\checkmark	IS	\checkmark	SE	1
DK	\checkmark	ES	1	CZ	1	NL	\checkmark	AT	\checkmark	LV	\checkmark	SK	~
FR	\checkmark	UK	\checkmark	FI	\checkmark	ΡT	\checkmark	CY	\checkmark	MT	\checkmark	PL	\checkmark
HU	\checkmark	NO	\checkmark	GR	\checkmark	S	\checkmark	EE	\checkmark				
IT	\checkmark	LU	<u> </u>	IE	1	СН	1	DE	1				

The device can be operated in the EU without restrictions indoor, but cannot be operated outdoors in France in the whole of the band until further notice

This product complies with the requirement of the 1999/5/EC directive.

Modifications

Modifications not authorized by the manufacturer may void user's authority to operate this product.



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/ EC.

Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.



Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

Information about the use of batteries:

Caution

- Risk of leakage: Only use the specified type of batteries. Do not mix new and used batteries. Do not mix different brands of batteries. Observe correct polarity. Remove batteries from products that are not in use for a longer period of time. Store batteries in a dry place.
- Risk of injury: Wear gloves when handling leaking batteries. Keep batteries out of reach of children and pets.
- Risk of explosion: Do not short circuit batteries. Do not expose batteries to excessive heat. Do not throw batteries into the fire. Do not damage or disassemble batteries. Do not recharge non-rechargeable batteries.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.





"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

AirPlay, iPod, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. iPad is a trademark of Apple Inc.

Class II equipment symbol:



CLASS II apparatus with double insulation, and no protective earth provided.



 The type plate is located on the bottom of the apparatus.

2 Your Entertainment System

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

If you contact Philips, you will be asked for the model and serial number of this apparatus. The model number and serial number are on the bottom of the apparatus. Write the numbers here:

Model No. ______ Serial No. _____

Introduction

Apple AirPlay technology enables you to play your iTunes music library, hosted on a Mac, PC, iPhone, iPod touch, or iPad on any AirPlayenabled device (for example, your DS3800W) connected to the Wi-Fi network. With an AirPlay-enabled device (for example,

your DS3800W), you can:

- stream audio from your iTunes music library to any room in your house
- choose which AirPlay-enabled devices you want to play music on (if you have more than one such devices in your house)
- stream audio to multiple AirPlayenabled devices at the same time (from the iTunes music library on your PC/Mac only)

🔆 Тір

• Please visit www.philips.com/welcome for information about more Philips AirPlay-enabled devices.

With DS3800W, you can also:

- charge your iPod/iPhone/iPad through the USB socket with an Apple USB cable (not supplied).
- play your iTunes music library on your iPod/iPhone/iPad through the USB socket directly while charging.
- play music from other audio devices through the **MP3-LINK** socket.

What's in the box

Check and identify the contents of your package:

- Main unit (with a built-in Wi-Fi module)
- 1 × AC power adapter
- 1 x MP3 link cable
- User manual (in CD-ROM)
- Quick start guide

What else you need

To stream audio wirelessly by AirPlay, you need:

- A Wi-Fi certified router
- A host for your iTunes music library, for example, an iPod touch/iPhone/ iPad installed with iOS 4.3 (or later) or a Wi-Fi enabled PC/Mac installed with iTunes 10 (or later)


Your DS3800W should be connected to the same local network as your iTunes host device through the Wi-Fi router.

List of compatible iTunes host devices for AirPlay

In terms of AirPlay, DS3800W is compatible with:

- a Wi-Fi enabled PC/Mac installed with iTunes 10 (or later); and
- the following iPod/iPhone/iPad models installed with iOS 4.3 (or later):
 - iPad 2
 - iPad
 - iPhone 4
 - iPhone 3GS
 - iPod touch (2nd, 3rd, and 4th generation)

Overview of the main unit



- 1 Power indicator
- - Turn the unit on/off.
- 3 ►II
 - Start or pause play.
- (4) +/-
 - Adjust volume.
 - (Press and hold both buttons) reset the unit.
- 5 DC IN
 - Connect the power adaptor.

- Connect the unit to a Wi-Fi network.
- Show the Wi-Fi connection status of the unit.
- 7 MP3-LINK
 - Connect an external audio player through the supplied MP3 link cable.
- ⑧ USB •<↔
 - Connect an iPod/iPhone/iPad through an Apple USB cable (not supplied).

Get started to use AirPlay

To get started with AirPlay, you need to:

- 1 Upgrade your iPod touch/iPhone/iPad to the latest iOS version (iOS 4.3 or later).
 - Or install the latest version of iTunes (iTunes 10 or later) on your PC/Mac.
- 2 Connect power to DS3800W, then turn it on (see 'Prepare' on page 10).
- 3 Connect DS3800W to your existing home Wi-Fi network (see 'Connect to your home Wi-Fi network for AirPlay' on page 11).
- 4 Make sure that your iPod touch/iPhone/ iPad or PC/Mac are also connected to the same Wi-Fi network.

3 Prepare

Always follow the instructions in this chapter in sequence.


Connect power

Caution

- Risk of product damage! Make sure that the power supply voltage matches the voltage printed on the bottom of the unit.
- Risk of electric shock! When you unplug the AC adaptor, always pull the plug from the socket. Never pull the cord.
- Before you connect the AC adaptor, make sure that you have completed all the other connections.

Turn DS3800W on

- 1 Press 🖱 on the top to turn the unit on.
- 2 Wait for successful boot-up of the unit.
 - \mapsto The boot-up takes about 35 seconds.
 - → During boot-up, the Wi-Fi SETUP indicator on the back of the unit blinks green quickly.
 - ➡ After boot-up, if no Wi-Fi connection has been set up for DS3800W, the Wi-Fi SETUP indicator starts to blink green slowly.
 - To turn the unit off, press එ again.



- Connect the AC power cord to
 - the DC IN socket on the back of the unit.
 - the wall power socket.

4 Connect to your home Wi-Fi network for AirPlay



To connect DS3800W to your existing home Wi-Fi network, you need to apply your home Wi-Fi settings to DS3800W.

You can do this in two ways (depending on which type of Wi-Fi router you use):

- Automatically if your Wi-Fi router is WPS (Wi-Fi Protected Setup)-enabled and supports PBC (Push Button Connection) (see 'Scenario 1: Connect to a WPS router' on page 11)
- Manually if your Wi-Fi router does not support WPS (see 'Scenario 2: Connect to a non-WPS router' on page 12)

Once connected successfully, DS3800W will remember your home Wi-Fi settings. Then you can enjoy AirPlay whenever DS3800W is powered on and connected to your home Wi-Fi network automatically. Before connection of DS3800W to you home Wi-Fi network, check the points below.

- 1 Make sure that your Wi-Fi router is powered on and working properly.
- 2 Make sure that DS3800W has been powered on and booted up successfully (see 'Turn DS3800W on' on page 10).
- 3 Identify the type of your Wi-Fi router (see the user manual of your Wi-Fi router for details).


Scenario 1: Connect to a WPS router

- Note

- Before you press any button on DS3800W, make sure that DS3800W has been booted up successfully (see 'Turn DS3800W on' on page 10).
- 1 Press the WPS button on your home Wi-Fi router.



- 2 Shortly after step 1, press Wi-Fi SETUP on the back of DS3800W.
 - → The Wi-Fi SETUP indicator blinks red, yellow and green alternately.
 - → Within 2 minutes, the WI-FI SETUP indicator stops blinking and stays green, and the unit beeps.
 - → DS3800W is connected to your home Wi-Fi network successfully.



🔆 Тір

- For some Wi-Fi routers, you may need to hold the WPS button for Wi-Fi connection or enable the WPS PBC function from the router configuration pages. See the user manuals of the specific routers for details.
- If the Wi-Fi SETUP indicator on DS3800W blinks yellow, it means that the Wi-Fi connection has failed. Please wait for 2 minutes and try again. If the problem remains, try to set up the Wi-Fi connection manually (see 'Scenario 2: Connect to a non-WPS router' on page 12).
- If the Wi-Fi connection fails again, press and hold both the + and - buttons on the top of DS3800W to reset it, and then try again.

Scenario 2: Connect to a non-WPS router

- Note

• You can also follow the procedures below to connect DS3800W to a WPS router manually.

To connect DS3800W to a Wi-Fi router manually, you need access to DS3800W's built-in configuration web page for change of its internal Wi-Fi settings. To do so, you need a Wi-Fi enabled device with an Internet browser for temporary Wi-Fi connection to DS3800W. The Wi-Fi enabled device can be an iPod touch/ iPhone/iPad or a Wi-Fi enabled PC/Mac. Follow the sequence below for connection of DS3800W to a non-WPS Wi-Fi router.

- 1 Collect settings of your home Wi-Fi router and write down on paper for use during DS3800W Wi-Fi setup (see 'Collect settings of your home Wi-Fi router' on page 13).
- 2 Switch DS3800W to Assisted Wi-Fi Setup mode (see 'Switch DS3800W to Assisted Wi-Fi Setup mode' on page 13).
 - → A new Wi-Fi network created by DS3800W will appear, with the network name (SSID) of Philips Fidelio AirPlay.
- 3 Connect your Wi-Fi enabled device to the created new Wi-Fi network temporarily (see 'Connect your Wi-Fi enabled device to the newly created Wi-Fi network' on page 14).
- 4 Open the built-in web page of DS3800W with the Internet Browser of your Wi-Fi enabled device (see 'Open the built-in web page of DS3800W' on page 15).
- 5 Change the internal Wi-Fi settings of DS3800W based on the settings you wrote on paper at step 1 (see 'Change the internal Wi-Fi settings of DS3800W' on page 16).

Collect settings of your home Wi-Fi router


Note

- Always consult the user manual of your home Wi-Fi router for detailed instructions.
- 1 Connect your Wi-Fi enabled device to your existing home Wi-Fi network.
- 2 Launch the Internet browser (for example, Apple Safari or Microsoft Internet Explorer) on your Wi-Fi enabled device.
- 3 Open the configuration page of your home Wi-Fi router.
- 4 Find the Wi-Fi settings tab and write down the following information on paper:
 - (A) Network name (SSID)
 - (B) Wi-Fi security mode (usually WEP, WPA or WPA2 if enabled)
 - C Wi-Fi password (if Wi-Fi security is enabled)
 - (D) DHCP mode (enabled or disabled)
 - (E) Static IP address settings (if DHCP mode is disabled)

Switch DS3800W to Assisted Wi-Fi Setup mode



 Before you press any button on DS3800W, make sure that DS3800W has been booted up successfully (see 'Turn DS3800W on' on page 10).



- Press and hold Wi-Fi SETUP on the back of DS3800W for more than 5 seconds.
 - → The Wi-Fi SETUP indicator blinks green and yellow alternately.
 - → A new Wi-Fi network created by DS3800W will appear, with the network name (SSID) of Philips Fidelio AirPlay.
 - → It may take up to 45 seconds for successful creation of this new Wi-Fi network.

Note

- After you finish manual Wi-Fi setup for DS3800W, the new Wi-Fi network created by DS3800W will disappear.
- If you fail to enter Assisted Wi-Fi Setup mode, power off DS3800W and power on it, then try again after successful boot-up.
- · Make sure that there are no other Philips AirPlayenabled devices in Assisted Wi-Fi Setup mode at the same time. Multiple Wi-Fi networks created this way may interfere with each other.

Connect your Wi-Fi enabled device to the newly created Wi-Fi network

The new Wi-Fi network created by DS3800W only allows access of one Wi-Fi enabled device. To avoid interference from any other Wi-Fi devices, you are recommended to temporarily disable the Wi-Fi function on your other Wi-Fi devices.

Option 1: Use your iPod touch/iPhone/iPad

 Select Settings -> Wi-Fi on your iPod touch/iPhone/iPad.

Settings	
Firplane Mode	OFF
🕤 Wi-Fi	
Notifications	< bit >
Carrier	>
Sounds	>
Brightness	>
Wallpaper	>
General	>

2 Select Philips Fidelio AirPlay from the list of available networks.



- 3 Wait until successful Wi-Fi connection on your iPod touch/iPhone/iPad.
 - →

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 r

 </p


⊁ Тір

• If **Philips Fidelio AirPlay** is not in the list, try to scan the available Wi-Fi networks again.


Use your Wi-Fi enabled PC/Mac

- Note


- See the user manual of your PC/Mac for how to connect your PC/Mac to a Wi-Fi network.
- During Wi-Fi network connection, do not connect any network cable to your PC/Mac.
- 1 Open the Wi-Fi setup tool or control panel on your PC/Mac.



3 Select Philips Fidelio AirPlay from the list of available networks.



4 Wait until successful Wi-Fi connection on your PC/Mac.




Tip

 If Philips Fidelio AirPlay is not in the list, try to scan the available Wi-Fi networks again.

Open the built-in web page of DS3800W


- 1 Launch Apple Safari browser or any other Internet browser on your Wi-Fi enabled device.
- 2 Type in **192.168.1.1** at the browser address bar and confirm.
 - → The DS3800W configuration web page is displayed.



If you use Safari on your Wi-Fi enabled PC/ Mac, you can also select 'Philips_Fidelio XXX' from the Bonjour pull-down list to enter the DS3800W configuration web page directly.

1 Click ***** -> Preferences.

→ The Bookmarks menu is displayed.



2 Tick Include Bonjour for Bookmarks bar.

eneral Appenance Incitmatic Table RSS Autoful Security Extensions Advanced	
Bookmarke bar: Docksda Too Stee	
Boolmarks menur Include boolizarias bar	
bookingers menu. Disclude bookinging bar	
Collections: Disclude Bonjour	
	(?)

- **3** Select 'Philips_Fidelio XXX' from the Bonjour pull-down list shown at the bookmarks bar.
 - → The DS3800W configuration web page is displayed.



Change the internal Wi-Fi settings of DS3800W

On the DS3800W configuration web page, you can change the internal Wi-Fi settings of DS3800W for connection of DS3800W to your existing home Wi-Fi network.



 Make sure that the settings on the configuration web page match your home Wi-Fi network settings that you wrote on paper.



- Follow the on-screen instructions to change and confirm the internal Wi-Fi settings of DS3800W.
 - ➡ After a while, the indicator on the back of DS3800W stops blinking and stays green, and the unit beeps.
 - DS3800W is connected to your existing home Wi-Fi network successfully.

- Note

- If the WI-FI SETUP indicator on DS3800W does not stay green steadily, it means that the WI-Fi connection has failed. Please power off both your WI-Fi router and DS3800W and then power on them again to see whether DS3800W can be connected to your home WI-Fi network. If the problem remains, try the above procedures again.
- After you finish the above changes or power-off and power-on of DS3800W, the new Wi-Fi network created by DS3800W will disappear.

🔆 Тір

- If you like, you can change the name of your DS3800W in Advanced settings -> AirPlay Device Name on the DS3800W configuration web page. This is helpful when you have multiple Philips AirPlay-enabled devices in your house and you need to distinguish between them.
- If you want to enter the network name (SSID) manually (for example, if you want to hide your SSID), go to Advanced settings -> CONFIGURE MANUALLY on the DS3800W configuration web page.

Restore your Wi-Fi enabled device back to your existing home Wi-Fi setting



- Make sure that the settings at steps 2 to 3 below match your home Wi-Fi network settings you wrote on paper:
- 1 Select Settings -> Wi-Fi on your iPod touch/iPhone/iPad.
 - Or open the list of available Wi-Fi networks on your PC/Mac.

Settings



2 Select your network name (SSID) from the list of available wireless networks.



3 E

4

Enter the network key if required.

Wait until successful Wi-Fi connection to your home Wi-Fi network.

5 Play


Stream audio from your iTunes music library to **DS3800W**



 Make sure that your iTunes host device is connected to the same Wi-Fi network as DS3800W.Your iTunes device can be an iPod touch/iPhone/iPad installed with iOS 4.3 (or later) or a Wi-Fi enabled PC/Mac installed with iTunes 10 (or later).

Stream from your iPod touch/iPhone/ iPad

- 1 Launch the iPod application on your iPod touch/iPhone/iPad.
- 2 Tap on the AirPlay icon.



3 Select Philips Fidelio XXXX (or user customized name) from the AirPlay list.



- 4 Select a media file and start play. → After a while, you will hear music from
 - DS3800W.





Note

- If you fail to hear music after successful setup, do one of the following on your iPod touch/iPhone/iPad:
- . (1) Disconnect and then re-connect to the same Wi-Fi router again;
- (2) Close all applications running at the background;
- . (3) Power off and then power on your iPod touch/ iPhone/iPad again.

Stream from your PC/Mac

- 1 Launch iTunes 10 (or a later version) on your PC/Mac.
- 2 Click the AirPlay icon on the window.

to 24 per prior pr	in Manual Sec.		-				
0.00	Conception in the local division of the loca		£			Artest.A.C.	_
	Market and	The \$100	terrer 1 Autor	-			_
1.000	a recordence	0.00 40 40 40					
line .	and an address to the testing of						
OF TO Base	10 # 1540-51VM	And institution					
These .	1 If and take	Ant the Contemport	(mail)				
- Auto	18 P begin Parter	All Participants	land d				
	If it causes weren	the stand works					
D.Freehow	A CONTRACTOR	THE CONTRACTOR					
	1 4 480	All sectors					
C-bee here	10 of some set (harrings) in	and some					
	d of Ballena Mr.	the most loss	test .				
Net CALCO	10 If wanted as seen	to repaired					
1.044	of additional residue						
and in the second	2 4 44	AND INCOMES					
D-Aventer -	A of Party Station	hit hat have	dame.				
a strategy	a statement of the						
Concerne .	4 Sectores		-				
And Man .	of Cardward and						
2-M Tanhana							
In Americanian				-			
it being being							
10 fog itt that filled							
				_			
					the second second second		
					and the second se		
					and the second se		
					and the second se	_	1
					the second s		
					No. of Concession, Name		
				_			-
							1
			-				

3 Select Philips_Fidelio_AirPlay XXXX (or user customized name) from the AirPlay list.

the local data					-						
000	1000	-			s			_		Chinese .	_
1.01	Marily NY 1	- Terro		The arts	-	-	-	_	_		-
-		FALLEFORM		201.00.0010							
-		· · · · · · · · · · · · · · · · · · ·		IN DRIND							
1. den		a chilefoniar		or permanent							
tank .		a seatored		OR Technism							
		/ Angle Techn		All Substants	best .						
		· · · · · · · · · · · · · · · · · · ·									
Associated											
10000				42 million							
Anter Stratig		· · · · · · · · · · · · · · · · · · ·	topents.	And include house	-						
					-						
-		Y ADDRESS AND THE OWNER		IN HEIGHT							
		1.00			-						
dana da la		1.00									
an ing	-										
Deserve.											
And Mark		1.14	-								_
in hailant				122102010000							
Annual Adda				My Compu	ter						
Annual Street							_				
The State Second				Philps Fid	lin 21	COOD					
				"nuips_nui	510 21	onon.					
			-								
			100						- 10-		
			l Mu	Itiple Speak	ers			9778 S.	888		
			23.2		20222584				C.C.W.		
											_
										Determ	
										C CALING	100
										Co. Successo	
CONTRACTOR OF											

4 Select a media file and start play.

→ After a while, you will hear music from DS3800W.

	the defendence of the				the second						
		-		144.5	the Peri			1000		Charles and	_
Contraction of Contraction	Start and			The Arts	-	Autor	-	_	and the second		-
	Statute of Lot	1 1.111		And all address	-		-				
200		a signature		AN ADDRESS							
to Base		Contraction of		And institute states							
and and a second se		d and the		All Rationer							
Aug.		a heigh he		All Reliators	-						
		A CANADA		An other state							
free box	-	A HOUSE		THE CONTRACTOR							
Parent lands		1.000		All sectors							
	-		anima to can when	and particulations							
here there				10 million							
1077 (h		d being		the same new	-						
			HOURS IN COMPANY		-						
		1.44		An Interfaction							
		-		Apr. Natio Instant	1400						
finite.		1 246,40		An insteriostim.							
Contract .		V Last, No.									
] Philips_	Fide	elio 2	158	зв	2838	_	
				Philips_	Fide	elio 2	158	i3B	北		
] Philips_	Fide	elio 2	158	i3B	\$¥		
				Philips_			158	:3B	2Å		

🔆 Тір

- When you stream audio from your iTunes music library on a PC/Mac, you can select more than one AirPlayenabled devices (if available) at step 3 to stream music to all of them at the same time.
- If you are using an earlier version of iTunes, the AirPlay icon may be \$ instead of .

Control play

You can select different play options from either your iTunes host device or DS3800W.

- Note

- Make sure that you have successfully streamed audio from your iTunes music library to DS3800W.
- To pause or resume play, press ► II.
- To adjust volume, press +/- repeatedly.

🔆 Тір

 If you are streaming music from a PC/Mac, to control music play from DS3800W, remember to tick Allow iTunes audio control from remote speakers in Edit -> Preferences -> Devices on iTunes.

Use advanced sound settings

If your iTunes host device is an iPod touch/ iPhone/iPad:

For advanced sound settings and additional features, you can use your iPod touch/iPhone/ iPad to download the **Philips Fidelio** application from Apple App Store. It is a free application from Philips.

If your iTunes host device is a Wi-Fi enabled PC/Mac:

For advanced sound settings, you can use the equalizer available on iTunes directly (View -> Show Equalizer).

🔆 Тір

• See the iTunes help documentation for more details.


Play/charge your iPod/iPhone/ iPad through USB socket

- Note

• The USB socket is only compatible with iPod/iPhone/ iPad.

You can play or charge your iPod/iPhone/iPad through the USB socket with an Apple USB cable (not supplied).

If you have stopped audio streaming by AirPlay, after successful USB connection, the unit switches to the USB source automatically.



- Connect an Apple USB cable (not supplied) to:
 - the USB •← socket on the back of DS3800W.
 - the dock connector on your iPod/ iPhone/iPad.

Compatible iPod/iPhone/iPad


The USB socket supports play and charge of the following iPod, iPhone, and iPad models.

- iPad 2
- iPad
- iPhone 4
- iPhone 3GS
- iPhone 3G
- iPhone
- iPod classic
- iPod 5G
- iPod 4G
- iPod nano (2nd, 3rd, 4th, 5th, and 6th generation)
- iPod touch (1st, 2nd, 3rd, and 4th generation)

Play from an external device

You can also listen to an external audio player through the unit.

If you have stopped both audio streaming by AirPlay and direct music play through the USB socket, DS3800W switches to the MP3 link source automatically.



- Connect the supplied MP3 link cable to:
 - the MP3-LINK socket on the back of the unit.
 - the headphone jack on an external audio player.

6 Update firmware

To improve the performance of DS3800W, Philips may offer you new firmware for upgrade of your DS3800W.

Please register your product at www.philips.com/welcome for information about the latest firmware.

- Note

• You can only update the firmware from a PC/Mac.

Download the update file



- 1 On your PC/Mac, go to www.philips.com/support.
- 2 Enter the model number to find the latest firmware upgrade file available.
- **3** Save the upgrade file to your hard drive.


Update from the configuration page

Warning

 Always connect your DS3800W to AC power for firmware upgrade. Never power off your DS3800W during firmware upgrade.

- Note

- To use an Internet browser other than Apple Safari on your PC/Mac, remember to go to the Wi-Fi router configuration page and write down the IP address of your DS3800W. See the user manual of your Wi-Fi router for how to find the IP addresses of devices connected to the Wi-Fi router.
- 1 Power on DS3800W (see 'Prepare' on page 10).
 - → It takes about 35 seconds for the unit to boot up. During boot-up, the WI-FI SETUP indicator on the back of the unit blinks green quickly.
 - → After boot-up, you can hear a beep and the WI-FI SETUP indicator turns to green steadily. DS3800W is connected to the last configured Wi-Fi network automatically.
- 2 Make sure that DS3800W and your PC/Mac are connected to the same Wi-Fi router.
- 3 Open Apple Safari on your PC/Mac, then select 'Philips_Fidelio XXX' from the Bonjour pull-down list.
 - Or open any other Internet browser on your PC/Mac, then type in the IP address of DS3800W (available on the Wi-Fi router configuration page) at the address bar.
 - → The DS3800W configuration web page is displayed.



4 Follow the on-screen instructions to complete the firmware update.

Note

- In case the firmware update fails, you can try the above procedures again.
- After successful firmware update, if there is any problem with the Wi-Fi connection, press and hold both the + and - buttons on DS3800W for more than 5 seconds at the same time to reset the device, and then try to set up the Wi-Fi network for DS3800W again (see 'Connect to your home Wi-Fi network for AirPlay' on page 11).

7 Product information

- Note

• Product information is subject to change without prior notice.

Specifications

Amplifier

Rated Output Power	4 X 4 W RMS
Frequency Response	63 - 20 kHz
Signal to Noise Ratio	> 75 dB
MP3 Link	650 mV RMS 20 kohm

Speakers

Speaker Impedance	8 ohm
Speaker Driver	40 mm full range
Sensitivity	78 dB/m/W

Wireless

Wireless	802.11b/g
standard	
Wireless	WEP (64 or 128 bit),
security	WPA/WPA2 (8-63 characters)
Frequency	2412 - 2462 MHz (CH1-
range	CH11) (for /79, /37, /55, /97)
	2412 - 2472 MHz (CH1-
	CH13) (for /12, /10, /05)
PBC (one	Yes
button push)	

General information

AC power	Input: 100 - 240 V~,
	50/60 Hz 1A/1.2 A
	Output: 12 V === 3.0 A
Operation Power	30 W
Consumption	
Power Consumption in	≤ 0.5 W
Standby Mode	
Dimensions	
- Main Unit (L x W	198 x 100 x 196 mm
× H)	
Weight	
- With Packing	1.71 kg
- Main Unit	1.05 kg

8 Troubleshooting

Warning

• Never remove the casing of this apparatus.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using this apparatus, check the following points before requesting service. If the problem remains unsolved, go to the Philips web site (www.philips.com/welcome). When you contact Philips, ensure that the apparatus is nearby and the model number and serial number are available.

No power

- Make sure that the AC power plug of the device is connected properly.
- Make sure that there is power at the AC outlet.

No sound

- Adjust the volume.
- Check the Wi-Fi network connection.
 Set up the network again if needed (see 'Connect to your home Wi-Fi network for AirPlay' on page 11).

No response from the unit

- Press and hold both the + and buttons on DS3800W for more than 5 seconds to reset the device. Then set up the Wi-Fi network for DS3800W again (see 'Connect to your home Wi-Fi network for AirPlay' on page 11).
- Disconnect and reconnect the AC power plug, and then switch on the device again.

Wi-Fi network connection failed

 Check if your Wi-Fi router is Wi-Fi 802.11b/g certified. This device is only compatible with Wi-Fi 802.11b/g certified routers.

- If your Wi-Fi router is Wi-Fi 802.11n certified, make sure to enable the 802.11b/g mode. DS3800W does not support connection to routers with 802.11n only.
- This device does not support the WPS-PIN method.
- If your Wi-Fi router supports WPS and the WPS-PBC method but fails to connect to DS3800W, try the manual Wi-Fi setup method (see 'Scenario 2: Connect to a non-WPS router' on page 12).
- Enable SSID broadcast on the Wi-Fi router.
- Keep away from potential sources of interference which may affect Wi-Fi signal, such as microwave ovens.
- If you fail to use your PC for Wi-Fi network setup, check whether your PC is using a Wi-Fi network. You cannot use Ethernet connection for AirPlay network setup.
- Make sure that the SSID name of your home router consists of alphanumeric characters, with no space or special characters like %/#/* inserted.
- If you choose to rename the AirPlay device 'Philips_Fidelio XXXX' in the setting menu, do not use special characters or symbols.
- For some new types of Wi-Fi routers, a network name (SSID) may be created automatically when you use WPS for connection. Always change the default network name (SSID) to a simple one that consists of alphanumerical characters, and also change the Wi-Fi security mode to secure your network.

Occasional breaking of AirPlay music streaming

Do one or all of the following:

- Move DS3800W closer to your Wi-Fi router.
- Remove any obstacles between DS3800W and your Wi-Fi router.
- Avoid using Wi-Fi channel which is overlapped by the nearby Wi-Fi network.

- Check if your network speed is fast enough (in cases where multiple devices share the same router, the AirPlay performance may be affected).Turn off the other devices connected to your home router.
- Enable the Quality of Service (QoS) option (if available on the Wi-Fi router).
- Turn off other Wi-Fi routers.

No AirPlay icon on my iTunes host device

- Make sure that DS3800W is already connected to your home Wi-Fi network.
- Before you open iTunes, make sure that you have enabled Bonjour service in your PC. Take Windows XP for example: to enable the service, you can click Start->Control Panel, and double-click Administrative Tools-> Services->Bonjour Service, then click Start followed by OK on the pop-up menu.
- If the problem remains, try to restart DS3800W.

AirPlay connection failed with Mac or PC

- Temporarily disable the firewall and security software to see whether it blocks the ports that AirPlay uses to stream content. See the help documentation of your firewall and security software on how to unblock the ports used by AirPlay.
- When you use iPod Touch/iPhone/iPad/ Mac/PC for AirPlay, if the music play breaks or stops, try to restart your iPod Touch/ iPhone/iPad, iTunes or DS3800W.
- Video streaming or FTP downloads may overload your router and therefore may cause interruptions during AirPlay music play.Try to reduce the load of your router.





©2011 Koninklijke Philips Electronics N.V. All rights reserved. DS3800W_10_UM_V1.0