



Philips  
Digital PhotoFrame

26.4cm/10.4"  
16:9 frame ratio

SPF4610



## "...couldn't stop laughing that day!"

Keep your most memorable moments alive year round with Philips Photoframe. This compact frame is easy to use and looks good in any home environment.

### **Top quality display for amazing viewing experience**

- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

### **Simple intuitive operation and great convenience**

- Keep time with fun clocks
- Automatic slideshow from memory card
- Quick easy menu for browsing, searching, and organizing

### **Green design**

- Our packaging are small to minimize materials used
- Auto on/off display at pre-set times for power saving

# PHILIPS

# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 130° (H) / 110° (V), 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 16:9
- Panel resolution: 1024 x 600
- Brightness: 160 cd/m<sup>2</sup>
- Contrast ratio (typical): 500:1
- Effective viewing area: 1024x600

## Storage Media

- Built-in memory (RAM): 128MB (for 1000 photos)
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, Memory Stick, Memory Stick Pro

## Convenience

- Photo format supported: JPEG photo
- Card Reader: Built-in (1x)
- Placement: Landscape, Portrait
- Buttons and controls: 3 buttons
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Regulatory approvals: CE, GOST

## Accessories

- Included accessories: AC-DC Adapter
- User Manual: Dutch, English, French, German, Italian

## Dimensions

- Set dimensions with stand (W x H x D):

- 286.5 x 189.5 x 122 mm
- Weight: 0.58 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C

## Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: 3 W
- Power mode supported: AC powered
- DC output Ampère: 0.65 A
- DC output Volt: 5 V

## Packaging dimensions

- Type of shelf placement: Dummy
- EAN: 87 12581 60336 6
- Number of products included: 1
- Packaging dimensions (W x H x D): 33,5 x 26,5 x 6,5 cm
- Gross weight: 0,873 kg
- Nett weight: 0,553 kg
- Tare weight: 0,320 kg
- Packaging type: Dummy

## Outer Carton

- GTIN: 1 87 12581 60336 3
- Number of consumer packagings: 3
- Gross weight: 2,891 kg
- Outer carton (L x W x H): 34,5 x 20,6 x 28 cm
- Nett weight: 1,659 kg
- Tare weight: 1,232 kg

# Highlights

## Our packaging are small

We make our packaging as small as possible to minimize materials used in production as well as fuel during transportation.

## Keep time with fun clocks

Switch to the clock mode when you don't need to view photos. Instantly, your PhotoFrame become a clock.

## Automatic slideshow start up

Slideshow of photos starts automatically once you insert the memory card.

## imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.



Issue date 2014-02-13

Version: 2.1.4

12 NC: 8670 000 76416  
EAN: 87 12581 60336 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)