Philips DVD Micro Theater





Turn any room into a Theater

The uniquely stylish mirror-finished center-unit and wood-finished speakers are an alluring combination. The MCD703's prominent design complements its equally remarkable audio and visual technology within.

Enrich your movie experience

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- 12-bit/108MHz video processing for sharp and natural images
- Progressive Scan component video for optimized image quality
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- · Loudness for bass and treble enhancement
- Total 100W RMS

Design that blends into your interior(s)

- High-end component design with stand
- Elegant wood-finished speakers
- · High quality remote control for comfortable use



Highlights

12-bit/108MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colors, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Loudness

In the sound spectrum, high and low

frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

High-end component design

The component-designed micro system comes with a stand that features four triangular feet. It can prevent any audio frequency distortion due to vibration, overheating and electromagnetic interference generated from the amplifier and CD loader. The result is smooth and excellent sound reproduction.

High quality remote Control

The remote control is a perfect balance of dimensions and weight. Sleek and ergonomically designed, the bottom cover of remote control features a soft rubber-paint finish to ensure comfort in usage.











Specifications

Sound

- Output Power: Total 100W RMS
- Sound Enhancement: Loudness, Digital Sound Control 4 modes, Dynamic Bass Boost, Reverb Mode
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: 2 way, 4" woofer, Bass Reflex Speaker System, Speaker grilles detachable
- Subwoofer type: Passive

Video Playback

- Playback Media: DVD+RW, DVD-Video, Video CD/SVCD, Picture CD
- Video Enhancement: Progressive Scan
- Disc Playback Modes: Parental control, Angle, Zoom, Slow Motion, Dynamic Range Compression, PBC, A-B Repeat
- DVD Region.: 1

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD-RW, CD-R, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Top

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, AM
- Auto digital tuning

Station presets: 40

Connectivity

- Video Output Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Other connections: Active subwoofer Pre-out, Digital audio coaxial out, Digital optical out, FM Antenna, AM Antenna
- Aux in: 2x(L/R)/ RCA
- Headphone: 3.5 mm

Convenience

- Alarms: CD Alarm, Sleep timer
- Clock: On main display
- Display Type: White FTD
- OSD Languages: English, French, Spanish

Accessories

- Included accessories: Control cable, Composite video cable (Y), FM/MW Antenna
- Remote control: 49-key with 2xAAA batteries

Dimensions

- Set dimensions (W x H x D): 208 x 156 x 268 mm
- Main speaker dimensions (W x H x D): 145 x 230 x 218 mm
- Packaging dimensions (W x H x D): 793 x 278 x 380 mm
- Weight incl. Packaging: 18 kg
- Subwoofer dimensions (W x H x D): 180 x 280 x 330 mm



Issue date 2011-01-06

 $\ensuremath{\mathbb{C}}$ 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

www.philips.com

Version: 2.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 100 13172 UPC: 6 09585 11077 9