



Philips 5000 series
Blu-ray Disc/ DVD player

3D Blu-ray Disc playback

Built-in WiFi
DivX Plus HD



BDP5600

Blu-ray 3D and the best of Internet on your TV

Be amazed by the new dimension 3D Blu-ray brings to your movie experience at home. Enjoy the best of Internet on your TV, hassle-free with the speedy built-in WiFi-n. And playback more than ever before with DivX Plus HD.

Engage more

- Turn your Smartphone into a remote for Philips AV products
- SimplyShare to connect & stream all entertainment wirelessly
- USB 2.0 plays video/music from USB flash/hard disk drive
- Built-in WiFi-n for faster, wider wireless performance

Hear more

- Dolby TrueHD for high fidelity 7.1 surround sound
- DTS2.0 Digital Out

See more

- Blu-ray 3D Disc playback for a full HD 3D experience at home
- DivX Plus HD Certified for high definition DivX playback

PHILIPS

Highlights

Blu-ray 3D Disc playback



Full HD 3D provides the illusion of depth for a heightened, realistic cinema viewing experience at home. Separate images for the left and right eyes are recorded in 1920 x 1080 full HD quality and alternately played on screen at a high speed. By watching these images through special glasses that are timed to open and close the left and right lenses in synchronization with the alternating images, the full-HD 3D viewing experience is created.

DivX Plus HD Certified



DivX Plus HD on your Blu-ray player and/or DVD player offers the latest in DivX

technology to let you enjoy HD videos and movies from the Internet direct to your Philips HDTV or PC. DivX Plus HD supports the playback of DivX Plus content (H.264 HD video with high-quality AAC audio in an MKV file container) while also supporting previous versions of DivX video up to 1080p. DivX Plus HD for true HD digital video.

SimplyShare



Philips SimplyShare lets you share your music, movies & photos from tablet, smartphone & PCs to your home theater & Blu-ray player. You can stream all entertainment directly from your DLNA-enabled devices or use remote control to access & stream media files from your PC. For the best wireless experience, install the SimplyShare app on your tablet/ smartphone. You are now ready to enjoy all your entertainment effortlessly.

USB 2.0

The Universal Serial Bus or USB is an industry standard that allows high-speed, easy

connection of peripherals to PCs, consumer electronics and mobile products. The USB 2.0 provides better and faster performance - up to 40 times quicker than the USB 1.0 and with a data transfer rate of up to 480 Mbps from the original 12 Mbps. When plugged in, everything configures automatically. With USB 2.0, simply plug in your USB portable devices or hard disk drives, select the movie, music or photo and play away.

WiFi-n

WiFi-n, also known as IEEE 802.11n, is the new wireless network standard. It includes many new options to improve the quality of the wireless link, offering faster speed and wider range compared to previous WiFi standards. WiFi-n also features backward compatibility, which makes it possible for this player to transmit to and receive from routers that operate on older WiFi standards.



Specifications

Picture/Display

- Aspect ratio: 16:9, 21:9, 4:3
- Blu-ray 3D: Full HD 1080p
- D/A converter: 12Bit/148MHz
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan, Video upscaling

Sound

- D/A converter: 24 bit, 192 kHz
- Dynamic Range (1kHz): =90 dB
- Frequency response: (20kHz): = |0.2|dB (Max./Min. 2ch, DVD) Hz Hz
- Signal to noise ratio: = 100 dB
- Sound Enhancement: Night Mode
- Sound System: Dolby Digital 5.1, Dolby Digital Plus, Dolby True HD, DTS Digital Surround, DTS-HD High Resolution Audio, DTS-HD Master Audio

Video Playback

- BD Region Code: C
- Compression formats: DivX Plus™ HD, H.264, MPEG2, MPEG4 (AVC), XviD, MPEG1
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Pause, Repeat, Resume Playback from Stop, Search forward/reverse, Skip, Slow Forward, Standard Play, Zoom
- DVD Region Code: 5
- Video Enhancement: Deep Color, Progressive Scan, Video Upscaling, x.v. Color

Audio Playback

- Compression format: AAC, MP3, Ogg Vorbis, PCM, WAV, WMA

Still Picture Playback

- Compression format: GIF, JPEG, JPEG HD, JPEG Progressive, PNG
- Picture Enhancement: Rotate, Slideshow with music playback, Zoom

File Format

- Audio: aac, mka, mp3, wma
- Picture: GIF, JPEG, JPG
- Video: asf, avi, divx, flv, m2ts, mkv, mov, mp4, mpeg, mpg, wmv

Optical Playback Media

- Playable Discs: AVCHD, BD, BD R / BD RE, CD, CDDA, CD-R/CD-RW, DVD, DVD +R/+RW, DVD -R/-RW, SVCD, VCD

Connectivity

- Front Connections: USB 2.0

- Network connections: 802.11 b/g/n, Built-in WiFi
- Rear Connections: Analog audio Left/Right in, Digital coaxial out, Ethernet, HDMI output, USB 2.0, Composite video (CVBS) output
- Smart TV Plus: MyRemote App, SimplyShare

Convenience

- BD-Live(1GB USB memory needed)
- Child Protection: Parental Control
- Ease of Use: Fast wake up, MyRemote app
- EasyLink (HDMI-CEC): 21:9 format subtitle support, One touch play, One touch standby, Remote Control-Passthrough
- Firmware upgradeable: Firmware upgradeable via USB, Online firmware upgrade
- On-Screen Display languages: Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Norwegian, Polish, Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Turkish

Power

- Power consumption: 20 W
- Power supply: 220-240V, 50Hz
- Standby power consumption: 0.3 W

Accessories

- Included accessories: 2 x AAA Batteries, Power cord, Product Registration Card, Quick start guide, Remote Control, User Manual

Product dimensions

- Product dimensions (W x H x D): 36 x 4.2 x 21.9 cm
- Weight: 1.09 kg

Packaging dimensions

- Packaging type: Carton
- Number of products included: 1
- Type of shelf placement: Laying
- Packaging dimensions (W x H x D): 41.5 x 30 x 8.7 cm
- Gross weight: 1.66 kg
- Nett weight: 1.26 kg
- Tare weight: 0.4 kg
- EAN: 87 12581 68632 1

Outer Carton

- Number of consumer packagings: 1
- Outer carton (L x W x H): 41.5 x 30 x 8.7 cm
- Gross weight: 1.66 kg
- Nett weight: 1.26 kg
- Tare weight: 0.4 kg
- EAN: 87 12581 68632 1



Issue date 2015-08-16

Version: 5.1.7

12 NC: 8670 001 02588
EAN: 87 12581 68632 1

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com