

Philips
Portable TV

- 22.9 cm (9") LCD
- 3hr playtime
- DTV

PT902



Enjoy portable digital TV and FM radio

with built-in HDTV and FM tuner

With the Philips Portable TV PT902, you can enjoy free-to-air DTV in its 22.9 cm (9") widescreen and listen to FM radio programs. Compact design, it is a great companion for camping, gardening or just being outdoors.

Experience the digital interactive TV phenomenon

- 22.9 cm (9") TFT color widescreen LCD display
- Free-to-air digital TV channel reception
- Easy installation and automatic channel search

For ultimate convenience

- FM digital tuning
- Enjoy up to 3 hours playback with a built-in battery*
- Handy remote control for extra convenience
- Detachable antenna design lets you connect to other antennas
- Few buttons for simple and easy control

PHILIPS

Highlights

3 hours built-in battery*



This Philips player comes with a compact built-in rechargeable battery for long-lasting power. Up to 3 hours of continuous movie, photo and music playback enjoyment can be achieved on a single charge. Just plug in the power cable to recharge the player - it's that simple.

Easy installation and search

Installation and setup is simple and quick. The easy-to-follow user menu will guide you on how to set up the TV. The player automatically searches for all the TV channels available in your area, so you can enjoy your favorite TV programs right away.

22.9cm/9" TFT color widescreen



The high resolution color LCD display brings images to life, showing off your treasured photos, favorite movies and music with the same 'real life' rich detail and vibrant colors as high quality prints.



Detachable antenna design

The antenna on the Philips portable TV is completely detachable, allowing you to easily connect the TV up to an alternate (e.g., indoor or rooftop) antenna as needed. By doing so, you can be sure of reaching the best TV signal available wherever you are.

Free-to-air digital TV



Expand your entertainment experience and enjoy digital channel programs - for free. With digital TV broadcasting, you can receive free digital TV programs in your country. The signal is kept digital without any analog steps in between, to preserve the highest quality.

FM digital tuning



FM digital tuning

Specifications

Picture/Display

- Display screen type: LCD TFT
- Diagonal screen size (inch): 9 inch
- Resolution: 600(w)x220(H)x3(GB)

Tuner/Reception/Transmission

- Tuner bands: FM
- Cable: Unscrambled Digital Cable QAM
- Terrestrial: ATSC (8VSB)
- TV system: ATSC

Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

Convenience

- Battery charging indication
- Favorite list TV programs
- User Interface: On Screen Display on TV, Multiple subtitles supported

Video Decoding

- Aspect Ratio: 16:9, 4:3

Connectivity

- DC in: 9V ~ 12V
- Headphone jack: 3.5mm headphone jack x 1
- Other connections: FM Antenna in
- TV connection: F-type connector

Accessories

- AC/DC Adaptor: DC 9V, 1A, 110-240v, 50/60Hz
- Remote control
- User Manual: Multi language
- Included accessories: Aerial antenna

Power

- Battery Type: Built-in battery
- Battery lifetime: Up to 3 hrs*
- Rechargeable

Dimensions

- Product dimensions (WxDxH): 240 x 29x 182 (mm)
- Product weight: 0.6 kg
- Packaging type: D-box
- Packaging dimensions (WxHxD): 295 x 300 x 60 (mm)
- Master carton dimensions: 195 x 308 x 305 mm
- Master carton quantity: 3
- Master carton weight: 3.95 kg



Issue date 2013-06-23

Version: 1.1.2

12 NC: 8670 000 63794
UPC: 6 09585 19157 0

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Battery life of playtime is approximate and may vary depending on application condition. To optimize battery life, user should turn LCD backlight to minimum, connect to headphones (not built-in speakers) and listen at medium volume level, and use the product at room temperature.

* Battery life varies by use and settings.

* Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of charge cycles vary by use and settings.