

Philips
In-ear true wireless
headphones

6mm drivers/ closed-back
Bluetooth®
Blue

TAT3215BL



Your sounds. Your moves.

Wherever. Whenever. These splash- and sweat-resistant true wireless headphones give you great sound and up to 24 hours play time with their charging case. If you're on a long call, you can use just one earbud while the other one charges.

Easy pairing. Voice control.

- Smart pairing. Automatically find your Bluetooth device
- Easily wake your smartphone's voice assistant
- Multi-function button. Easily control music and calls
- Switch from music to phone calls with built-in microphone

Feels good. Looks good.

- Secure, comfortable fit
- Rubber ear-tip covers in small, medium, and large
- Soft wing tips for a secure fit and a tighter in-ear seal

Up to 24 hours play time

- 6 hrs per charge. 15-min charge for 1 hr play time
- 6 mm neodymium drivers. Clear sound, punchy bass
- IPX4 splash- and sweat-resistant
- Mono mode. Switch the mic between earbuds
- Portable USB-C charging case. Get up to 24 hours play time

PHILIPS

In-ear true wireless headphones
6mm drivers/ closed-back Bluetooth®, Blue

Highlights

IPX4



With an IPX4 rating, these true wireless headphones are resistant to splashing from any direction. They won't mind a little sweat, and you don't need to worry about getting caught out in the rain.

Portable USB-C charging case.



Hit the road with multiple charges in your pocket. You get up to 6 hours play time on a single charge, plus 18 extra hours from a fully charged case. A short 15-minute charge in the case gives you 1hr and of play time. A full charge of the case takes 2 hours via USB-C.

Mono mode



Need to take a call when your headphones are running low on power? Get more talk time by using

one earbud while the other one charges. The mic is automatically assigned to the earbud you're using, and you can simply swap over when needed.

Secure, comfortable fit

You get great sound from the 6 mm neodymium drivers and you can rock your tunes in real comfort thanks to the snug, lightweight design. Soft, interchangeable ear-tip covers help you find a comfortable in-ear fit.

Multi-function button

Don't like the current track? Skip it with a long press of the multi-function button. Want to reject a call and keep listening? One press will take care of that. The built-in mic with echo cancellation keeps sound clear when you do take a call.

Voice assistant

Wake your phone's voice assistant without touching your phone. Ask smartphone's voice assistant to play music, get directions and check informations, and more.

Smart Bluetooth pairing.

These earphones are ready to pair the instant you take them out of their charging case. Once they're paired, the earphones remember the last device they were paired with.

6 hrs per charge.

6 hrs per charge. 15-min charge for 1 hr play time

6 mm neodymium drivers.

6 mm neodymium drivers. Clear sound, punchy bass

Rubber ear-tip

Rubber ear-tip covers in small, medium, and large

Soft wing tips

Soft wing tips for a secure fit and a tighter in-ear seal

Switch from music to calls

Switch from music to phone calls with built-in microphone

TAT3215BL/00

Specifications

Sound

- Acoustic system: Closed
- Diaphragm: PET
- Magnet type: NdFeB
- Frequency response: 20 - 20 000 Hz
- Sensitivity: 90 dB

Connectivity

- Bluetooth version: 5.1
- Bluetooth profiles: A2DP, AVRCP, HFP, HSP
- Maximum range: Up to 10 m

Outer Carton

- Length: 37.5 cm
- Number of consumer packagings: 24
- Width: 27.5 cm
- Gross weight: 4.7 kg
- Height: 24.5 cm
- GTIN: 1 48 95229 11017 2
- Nett weight: 1.176 kg
- Tare weight: 3.524 kg

Convenience

- Call Management: Switch between 2 calls, Answer/ End Call, Reject Call

Inner Carton

- Length: 18.7 cm
- Number of consumer packagings: 3
- Width: 12.8 cm
- Height: 10.4 cm
- Nett weight: 0.147 kg
- Gross weight: 0.53 kg
- Tare weight: 0.383 kg
- GTIN: 2 48 95229 11017 9

Power

- Battery type: Lithium-Ion

Packaging dimensions

- Height: 18 cm
- Width: 9.5 cm
- Depth: 4 cm
- EAN: 48 95229 11017 5
- Gross weight: 0.178 kg
- Nett weight: 0.049 kg
- Tare weight: 0.129 kg

Product dimensions

- Height: 4.2 cm
- Width: 3.6 cm
- Depth: 6.5 cm
- Weight: 0.049 kg

Accessories

- Quick Start Guide
- USB cable: USB (Type-A to Type-C) cable

Design

- Color: Blue

UPC

- UPC: 8 40063 20135 4



Issue date 2024-03-25

Version: 10.2.2

EAN: 48 95229 11017 5

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com