

Philips  
Portable DVD Player

17.8 cm/7" dual-screen LCD



PET718



## Home and Away DVD

with a second LCD TFT and car adaptor

Double your entertainment pleasure on the go with the Philips PET718 featuring two 7" TFT LCD display screens! Simply plug in the second screen to share DVD movies or JPEG photos - perfect for in-car enjoyment. Comes with Smart Car Mount.

### Immerse in AV entertainment on the go

- Play DVD, DVD+/-R, DVD+/-RW and (S)VCD
- Plays MP3-CD, CD and CD-RW music
- Share JPEG image files with Picture CD

### Comfortable viewing anywhere

- 17.8 cm (7") TFT color LCD display for high quality viewing
- Watch movies in 16:9 widescreen format
- Expand movie enjoyment with dual TFT LCD screens
- Built-in quality stereo speakers

### For ultimate convenience

- Enjoy up to 2.5-hour playback with a built-in battery\*
- Smart Car Mount for ease-of-use
- Share entertainment fun with dual headphone jacks

# PHILIPS

# Specifications

## Picture/Display

- Display screen type: LCD TFT
- Diagonal screen size (inch): 7 inch
- Resolution: 480(w)x234(H)x3(RGB)
- LCD panel type: Anti-glare polarizer
- Brightness: 200 cd/m<sup>2</sup>
- Contrast ratio (typical): 250:1
- Effective viewing area: 154.1x86.6mm
- Pixel pitch: 0.107(w)x0.370(H)mm
- Response time (typical): 30 ms

## Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

## Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: Dolby Digital, MP3
- MP3 bit rates: 32 - 320 kbps
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Joliet

## Connectivity

- DC in: 9V
- Headphone jack: 3.5mm Stereo Headphone x 2
- AV output: Composite (CVBS) x1

## Convenience

- Battery charging indication
- Shock proof

## Accessories

- AC/DC Adaptor: DC-in 9V (110-240v, 50/60Hz)
- Cables: 1 x AV Cables
- Car kit: AY4128 (cigarette outlet adaptor, 12vDC)
- Remote control: AY5508 slim remote
- User Manual: English/Spanish/Portuguese
- Power cord: 1 pcs
- Second LCD screen: 7" TFT LCD x 1 pcs
- Smart car mount: 2 pcs

## Power

- Battery lifetime: 2.5 hours
- Battery Type: Built-in battery

## Dimensions

- Master carton dimensions: 255 x 308 x 355 mm
- Master carton weight: 7.65 kg
- Master carton quantity: 3
- Packaging dimensions (W x H x D): 345 x 295 x 78 mm
- Product dimensions (W x H x D): 203 x 40.4 x 149 mm
- Packaging type: D-box
- Product weight: 0.71 kg

# Highlights

## MP3-CD, CD and CD-RW music

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hours of music.

## Share picture CD (JPEG)

Multi-format playability allows you to view images on the go and play most disc formats for maximum disc compatibility and viewing pleasure.

## Dual TFT LCD display screens

Dual screens allow you to display same videos or images from the portable DVD players. Simply plug in and mount the screens on the headrests in your car. Now you can enjoy your favorite DVD movies and JPEG photos with family and friends at the backseats easily and comfortably.

## Smart Car Mount

To enjoy entertainment on the go, why not bring your portable DVD player from home on the road with you? A unique Car Mount system ensures ease-of-use, with a quick-release arm that facilitates easy removal of the player when not in use. You can bring the portable DVD player with you, leaving just the Mount behind in the car.



Issue date 2014-02-06

Version: 2.0.2

12 NC: 8670 000 41732  
EAN: 87 12581 43823 4

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.