

Philips
Micro music system

- Dock for iPod/iPhone/iPad
- DAB+

DCB2020



Relax to great music

Obsessed with sound

Dock and listen to your iPod/iPhone/iPad, or turn on the crystal-clear DAB+ radio. This sound system also connects to other music players via USB Direct or MP3 Link. Enjoy your favourites with the deep, powerful sound of Bass Reflex speakers.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 20 W RMS total output power

Enjoy your music from multiple sources

- Play and charge your iPod/iPhone/iPad
- Play MP3/WMA-CD, CD and CD-RW
- DAB and FM compatible for a complete radio experience
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback

Easy to use

- Motorised CD loader for convenient access
- Digital tuning with preset stations for extra convenience
- Radio Data System for station information and data services

PHILIPS

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most

important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play and charge iPod/iPhone/iPad



Enjoy your favourite MP3 music while charging your iPod/iPhone/iPad! The dock lets you connect your portable device directly to the Philips system so you can listen to your favourite music in superb sound. It also charges

your iPod/iPhone/iPad while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The system automatically charges your portable device while it is docked.

DAB and FM compatible



DAB (Digital Audio Broadcasting) digital radio is a new way of broadcasting radio, in addition to FM analogue transmission, via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.



Specifications

Sound

- Output power: 2 x 10 W RMS
- Sound enhancement: digital sound control, Dynamic Bass Boost

Loudspeakers

- Speaker drivers: 4" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, WMA-CD, USB flash drive
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Docking playback modes: fast forward and reverse, menu, up and down, next and previous track, play and pause
- Others: ID3-tag support

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- RDS: programme type, radio text, RDS clock set, station name
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug and play)
- DAB: Info display, Menu, Smart Scan

Connectivity

- Headphones: 3.5 mm
- MP3 Link: 3.5 mm stereo line in
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm, iPod Alarm
- Clock: On main display, sleep timer

- Charging device: iPod, iPad, iPhone
- Display type: LCD display
- Loader type: tray

Accessories

- Included accessories: AC Power Cord, FM antenna, DAB antenna, Quick Use Guide
- Remote control: 31-key remote
- User Manual: English

Dimensions

- Main unit width: 200 mm
- Main unit height: 118 mm
- Main unit depth: 210 mm
- Main speaker dimensions (W x D): 140 x 144 mm
- Main speaker height: 224 mm
- Packaging width: 576 mm
- Packaging height: 274 mm
- Packaging depth: 190 mm
- Gross weight: 4.5 kg
- Net weight: 3.94 kg

Power

- Power supply: 220-240 V, 50/60 Hz

iPad compatibility

- Compatible with: iPad, iPad 2

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod compatibility

- Compatible with: iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod touch 3rd generation, iPod touch 4th generation, iPod 4th generation, iPod 5th generation



Issue date 2013-05-31

Version: 1.1.5

12 NC: 8670 000 84888
EAN: 87 12581 62610 5

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com