

Philips Perfect sound  
Cordless phone with  
answering machine

## 6000 series

4 handsets Black

SE6554B



# Enhanced High Def Voice

For ultimate call clarity

With voice purity as clear as the bright color screen, the SE6 series combines outstanding sound and perfect color. You will be delighted with the new communication experience brought by this blend of color and sound.

### Never miss a call

- Digital answering machine
- 30-minute recording time
- Message-counter on Base

### Outstanding sound quality

- Enhanced speakerphone for real-life handsfree conversations
- Enhanced High Def Voice

### Pure convenience

- Bright color display
- Icon-driven color menu
- 200-name phonebook

**PHILIPS**  
sense and simplicity

# Specifications

## Picture/Display

- Backlight
- Backlight color: White
- Main Display Resolution: 98x67 pixel
- Main Display Technology: CSTN
- Main Display Type: Full Graphic

## Sound

- Handset ringers: Polyphonic
- Volume Control: Volume Control up/down

## Convenience

- Alarms: Alarm Clock
- Base Station keys: Answering machine keys, Paging key
- Battery charging indication
- Call Management: Call Waiting, Caller ID, Conference Call, Explicit Call Transfer, Microphone mute
- Ease of Use: Full Duplex Handsfree, Graphical User Interface, Keypad Lock, Menu Control
- Function: Easy Call
- Multi base capability: 1
- Multi handset capability: Up to 5 handsets
- Personalisation/Customization: Wallpaper
- Signal strength indication
- VIP group with own melody: Yes for each phonebook entry
- Backlit keypad: Yes (Amber on handset)
- Speakerphone - talk handsfree

## Network Features

- Antenna: Integrated on base, Integrated on handset
- Dialing: Tone, Pulse

## Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

## Answering Machine

- Plug & Play Answering machine
- Recording time capacity: Up to 30 min.
- Message counter on base

## Memory Capacity

- Call log entries: 50
- Phonebook: 200 names and numbers
- Redial List Capacity: 10

## Connectivity

- Headset: Via Jack Connector (Handset)

## Dimensions

- Base dimensions: 131 x 116 x 76mm
- Handset dimensions: 161 x 46 x 27.6mm

## Power

- Battery capacity: 750 mAh
- Battery type: AAA NiMH
- Kind of Battery: Rechargeable
- Mains power: AC 120V - 60Hz
- Number of batteries: 2 per handset
- Standby time: Up to 150 hours
- Talk time: Up to 12 hours

## Accessories

- Detachable belt-clip

# Highlights

## Enhanced speakerphone

Combine a high quality speaker, sophisticated signal processing, a real acoustic chamber and full duplex handsfree and you'll get the most natural reproduction of a conversation. Both sides can speak and be heard at the same time, like in a face-to-face conversation.

## Enhanced Hi Def Voice

Enjoy high quality conversation, with a level of clarity rarely heard before. Thanks to a high-quality speaker, sophisticated technology and to a real acoustic chamber, the audio spectrum reaches far beyond what's normally heard on a telephone.



Issue date 2012-10-05

Version: 1.1.5

12 NC: 8670 000 34993  
UPC: 6 09585 14514 6

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)