

Philips
Mini Hi-Fi System

MP3

FWM70









wOOx Technology

Hear the Bass. Feel the Difference!

For those who prize technology and a superb listening experience, simply immerse yourself in the power of wOOx Technology from this mini system. Sit back and enjoy music from your favorite MP3 music in dynamic, rich sounds.

Powerful sound you can hear and feel

- $2 \times 110W$ RMS/2 $\times 220W$ music power/3000W PMPO
- · Class 'D' digital amplifier for quality sound performance
- Front firing wOOx Technology speakers

Longer listening, greater enjoyment

- 3-disc changer for WMA/MP3-CD music playback
- Playback 30 hours of MP3-CD music
- Dual Logic Tape Deck with auto replay

Ready for gaming

- · Gameport connection to your game console
- · Game Sound modes for different types of games
- MIX-IT for mixing the game sound with your favorite music



Specifications

Sound

- Output Power: 2x110W RMS
- Sound Enhancement: Class "D" Digital Amplifier, Incredible Surround, Digital Sound Control, Virtual Ambience Control, wOOx technology, Game Sound, MIX-IT

Loudspeakers

- Main Speaker: 2" tweeter, 3 way, 6.5" woofer, Bass Reflex Speaker System, Piezo, Speaker grilles detachable, wOOx Bass Radiator
- Number of Loudspeakers: 2

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 99-Track Programmable, Fast Forward/Backward, Next/Previous Track Search, Repeat/one/disk/program
- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Cassette Deck Technology: Logic
- · Number of decks: 2
- · Cassette Playback Modes: Full Auto Stop

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- · Auto digital tuning
- Station presets: 40
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug

& Play)

Connectivity

- · Aux in: Line in, Gameport
- · Headphone: 3.5 mm
- Other connections: Composite video (CVBS) out, FM Antenna, MW Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- · Clock: On main display
- Display Type: FTD
- · Eco Power Standby: I watt
- Indications: album name, album number, Cd functions, date, DIM mode, time, track

Accessories

- Included Accessories: AC Power Cord, FM/MW Antenna, User Manual
- Remote control: 32-key with 2xAA Batteries

Dimensions

- Main speaker dimensions (W x H x D): 240 x 358 x 230 mm
- Packaging dimensions (W x H x D): 624 x 412 x 510 mm
- Set dimensions (W x H x D): 265 x 322 x 390 mm
- Weight incl. Packaging: 20.5 kg

Power

• Power supply: I20V, 60Hz

FVVI*I/U/U/

Product highlights

2x110W RMS/2x220W music power

Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Front firing wOOx Technology

3-disc changer for WMA/MP3-CD

30 hours of MP3-CD music

Dual Logic Tape Deck

Gameport connection

Game Sound modes

MIX-IT for mixing game sound



Issue date 2009-02-12

Version: 2.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 100 12909 UPC: 0 37849 96264 0

www.philips.com