

Enriched Bass Sound

Uncomplicated yet comprehensive, you'll appreciate the rugged AZ2060 with quality 2-way speakers for superb sound performance. Enjoy your favorite CD or 30 preset FM stations on the digital tuner in enriched sound - anytime, anywhere!

Bass sound experience

- Bass Reflex Speaker System
- Dynamic Bass Boost

Enjoy digital tuning

- Digital Tuner with 30-station presets
- Autostore Programming

Easy to use

- CD shuffle/program/repeat
- Stereo headphone socket
- Line-in connection
- Remote control



PHILIPS

Technical specifications

Sound

- Output power (RMS): 2 x 2W
- Sound system: Stereo
- Sound enhancement technology: 2 steps Dynamic Bass Boost
- Volume control: Jog (endless rotary)

Loudspeakers

- Main speaker: 2 x 4"/piezo
- Speaker system: Two way
- Loudspeaker enhancements: Bass Reflex System
- Loudspeaker grill: Metal

Audio Playback

- CD player: CD-R/RW compatible
- CD loader type: Toploader with manual door
- CD player enhancements: 20 track CD programmable
Shuffle play
Repeat one/all/program
CD next/previous track search
- Number of decks: 1
- Cassette deck technology: Mechanical

Audio Recording

- Recording media: Tape
- Recording enhancements: CD to Tape synchro start recording
Auto level control
- Line in

Tuner / Reception

- Tuning technology: Digital
- Tuner enhancements: Autostore presets
- Station presets: 30
- Antenna: Telescopic antenna for FM reception
Internal antenna for AM reception
- Tuner bands: FM stereo
AM
LW (For Europe only)

Connectivity

- Headphone: Yes, 1 x 3.5mm socket
- Line in: 1 x 3.5mm
- AC socket

Convenience

- Display: 7-Digit LCD

Accessories

- Remote control: 14 Keys (RC19414002)
- Cables: Main cord

Power

- AC/DC operation
- Battery type: 6 x 1.5V, R20

Dimensions

- Packaging type: D-box
- Product dimensions (WxHxD): 435 x 174 x 263 mm
- Product weight: 3.3kg
- Package dimensions (WxHxD): 493 x 210 x 314mm
- Weight incl packaging : 4.4 kg

Product highlights

Digital Tuner

Depending on the audio device, Digital Tuner lets you tune up to a maximum of 40 radio stations, memorizes up to 10 tuner presets, or delivers the 'best 10' FM stations based on reception quality. Digital Tuner scans through frequencies and locks on to each station located. By allocating favorite stations a preset number, Digital Tuner makes it quick and easy to return to those stations time and again without having to remember radio frequencies.

Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

Two-Way Speaker System

Two-Way Speaker System recreates the ambience and atmosphere of a recording studio in your living room through accurate stereo imaging. Simply "You Are There!". To reproduce the full audio frequency band, conventional speakers need large and small cones to reproduce low and high frequencies respectively. Often sound quality is compromised in favor of smaller design. By using a woofer to reproduce bass to mid frequencies and a tweeter for mid to high frequencies, the Two-Way Speaker System seamlessly plays back the full audio frequency with much less inter-modulation distortion.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

CD-Rewritable Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

