



Philips  
Uninterruptible power  
supply

## Battery back-up

8 outlets

SPB9160WA



# 30 min. runtime

## Back up your computer system

This advanced battery back-up features s-OV technology to isolate, regulate and protect your connected equipment. Offering genuine surge protection, it is the only UPS with UL surge protection listing.

### Ideal for computer workstations

- 1-line splitter
- Data line/phone protection
- Phone/data jack
- 6 ft USB cable
- Phone cord

### Ultimate performance design

- 600VA, 300W
- s-OV technology
- Automatic Voltage Regulator (AVR)
- Auto shutdown software
- \$1,000,000 connected equipment warranty

### Built-in convenience

- 6 ft power cord
- Audible alarm

**PHILIPS**  
sense and simplicity

Uninterruptible power supply  
Battery back-up 8 outlets

# Specifications

## Packaging

- Quantity: 1
- Gross Weight: 8.868 kg
- Tare Weight: .748 kg
- Net Weight: 8.097 kg
- Length: 53.3 cm
- Width: 18.4 cm
- Height: 25.4 cm

## Outer Carton

- EAN/UPC/GTIN: 1 06 09585 13209 9
- Quantity: 2
- Gross Weight: 19.096 kg
- Tare Weight: .227 kg
- Net Weight: 18.869 kg
- Length (cm): 52.1 cm
- Width (cm): 19.7 cm
- Height (cm): 55.1 cm

SPB9160WA/17

# Highlights

## 1-line splitter

These connectors route the telephone line through the surge protector and split the line to allow two devices to be connected. It offers the convenience of leaving two devices connected constantly even though they may not be used simultaneously

## Data line/phone protection

These connectors accommodate either an RJ45 or an RJ11 cord. They route either line through the surge protector to guard against spikes and surges that may occur in the data or phone lines.

## Phone/data jack

MOVs or sidactor are used for protecting the phone or network lines. They protect against surges/spikes through the phone or network lines.

## 600VA, 300W

This power rating advises how much total power you are able to back up without overloading the battery.

## s-OV technology

This technology automatically senses an overvoltage and reacts quickly by completely disconnecting power from the main source, while continually delivering power to connected equipment from battery power. Power will be automatically reconnected to the main source once the surge event is over.

## AVR

Provides consistently clean power. Adjusts power to the nominal level if the input power is a too high or low.

## Auto shutdown software

Ensures that all open files are saved and computer shuts down safely without completely draining the battery

## \$1,000,000 equipment warranty

Protects your connected equipment for the life of the product.

## 6 ft power cord

Provides power to the unit which can be 6 feet from the AC outlet.

## 6 ft USB cable

Connects computer to UPS so that power monitor and auto shutdown can be executed.

## LED indicators

These LED indicators inform you of unit status at a glance

## Phone cord

Allows you to connect a phone or fax machine



Issue date 2009-11-06

Version: 5.0.6

12 NC: 8670 000 29616  
UPC: 6 09585 13209 2

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)