

Philips  
DVD home theater system



HTS3566D



# High definition home cinema

Dock included for iPod

Indulge in an unbeatable home cinema experience with this system. Delivering incredible surround sound and clear pictures via HDMI 1080p upscaling, it also plays from virtually any type of disc and from USB drives and portable media players

## Connect and enjoy multiple sources

- Dock included for convenient playback from your iPod/iPhone
- Hi-Speed USB 2.0 Link plays video/music from USB flash drive
- MP3 Link plays music from portable media players

## Bring audio and video to life

- HDMI 1080p upscales to high definition for sharper pictures
- Dolby Digital and Pro Logic II surround sound

## Play all your movies and music

- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- DivX Ultra Certified for enhanced playback of DivX videos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

## Easy to set up and use

- EasyLink to control all HDMI CEC devices via a single remote
- Floor standing speakers for freedom of placement
- Easy-fit™ connectors with color-coding for a simple set-up

# PHILIPS

# Highlights

## HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

## Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

## Plays it all

Play virtually any media format you want - whether they be WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

## EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/

RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## Dolby Digital and Pro Logic II

A built-in Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

## Floor standing speakers

Floor standing speakers for freedom of placement

## Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.



# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan

## Sound

- Output power (RMS): 4x125W, 2x250W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 180-14000 Hz
- Signal to noise ratio: >65 dB
- Sound System: Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Rock, Action, Classic, Concert, Drama, Lounge, Gaming, Sports

## Video Playback

- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG1, MPEG2, WMV
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC

## Audio Playback

- Compression format: MP3, WMA
- Playback Media: CD-R/RW, CD, USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

## Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, CD-R/RW, DVD-R/-RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

## Tuner/Reception/Transmission

- No. of preset Audio Channels: 40
- Tuner Bands: FM

## Connectivity

- Front / Side connections: Hi-Speed USB, MP3 Line-in
- Rear Connections: HDMI output, Component Video output, S-Video out, Composite video (CVBS) output, AUX in, FM Antenna, Easy-Fit Speaker Connectors, Digital coaxial in

## Power

- Power supply: 120V, 60Hz
- Standby power consumption: < 1 W
- Power consumption: 180 W

## Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 6 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center Speaker: Magnetically shielded, 3 way
- Center speaker drivers: 1 x 2" tweeter, 2 x 2.5" woofers
- Center speaker impedance: 3 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 8" high efficiency woofer
- Subwoofer impedance: 3 ohm

- Subwoofer freq range: 40-150 Hz
- Subwoofer type: Passive
- Satellite Speaker: 2 Floor standing pillars

- Weight: 0 kg

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, Product Registration Card, Quick start guide, User Manual, World Wide Warranty leaflet

## Dimensions

- Set dimensions (W x H x D): 435 x 58 x 360 mm
- Set weight: 3.7 kg
- Front Speaker Width: 103 mm
- Front Speaker Height: 203 mm
- Front Speaker Depth: 71 mm
- Front Speaker Weight: 0.56 kg
- Rear Speaker Width: 262 mm
- Rear Speaker Height: 1199 mm
- Rear Speaker Depth: 264 mm
- Rear Speaker Weight: 3.53 kg
- Center speaker dimensions (W x H x D): 244 x 105 x 74 mm
- Center Speaker Weight: 0.84 kg
- Subwoofer dimensions (W x H x D): 163 x 363 x 369 mm
- Subwoofer Weight: 5.08 kg
- Packaging dimensions (W x H x D): 970 x 435 x 410 mm
- Weight incl. Packaging: 22 kg

## Outer Carton

- Gross weight: 22.35 kg
- Gross weight: 49.273 lb
- Outer carton (L x W x H): 38.2 x 16.1 x 17.1 inch
- Outer carton (L x W x H): 97 x 41 x 43.5 cm
- Nett weight: 19 kg
- Nett weight: 41.887 lb
- Tare weight: 7.385 lb
- Tare weight: 3.35 kg
- Number of consumer packagings: 1
- UPC: 6 09585 14694 5

## Packaging dimensions

- Packaging dimensions (W x H x D): 97 x 43.5 x 41 cm
- Packaging dimensions (W x H x D): 38.2 x 17.1 x 16.1 inch
- Gross weight: 22.35 kg
- Gross weight: 49.273 lb
- Nett weight: 41.887 lb
- Nett weight: 19 kg
- Tare weight: 7.385 lb
- Tare weight: 3.35 kg
- Number of products included: 1
- Packaging type: Carton
- UPC: 6 09585 14694 5

## Product dimensions

- Cable length: 0 cm
- Cable length: 0 inch
- Product dimensions (W x H x D): 0 x 0 x 0 inch
- Product dimensions (W x H x D): 0 x 0 x 0 cm
- Weight: 0 lb



Issue date 2014-02-06

Version: 7.0.10

12 NC: 8670 000 36344  
UPC: 6 09585 14694 5

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)