

Philips
In ear headphones with mic

8.6mm drivers/semi-closed back
In-ear

SHE9105RD



Enjoy high performance precision sound

with solid metal housing

The Philips SHE9105 headphones boasts premium drivers and precision-crafted metal housing for detailed yet pure sound. Oval sound tubes & choice of 3 ear-tips ensure comfort and fit, while in-line mic lets you switch from music to calls.

Enjoy quality sound

- Sturdy aluminum housing prevents vibration for sound clarity
- Fine-tuned neodymium drivers for high frequency clarity

Ultimate wearing comfort

- Silicon caps in choice of three sizes for customized fit
- Curved housing and oval sound tubes for ergonomic comfort

Always ready to go

- Anti-tangle slider keeps your cables together neatly
- Durable Flexi-grip for strong headphone-to-cable connection
- Featuring in-line remote with mic for music and calls

PHILIPS

In ear headphones with mic
8.6mm drivers/semi-closed back In-ear

Highlights

Aluminum housing



The headphone's housing is crafted from sturdy aluminum, which prevents vibration for the purest sound performance. In addition, it protects the earphones from the wear and tear of everyday use.

Anti-tangle slider



The smart anti-tangle slider helps you easily keep the two earpiece cables neatly together, simply by gliding it up. No more hassles with tangles or knots!

Durable Flexi-grip connection

This soft yet durable and flexible connector between the earphone and cable helps protect against potential damage from repeated bending.

Finely tuned neodymium driver



Neodymium is the ideal material that produces strong magnetic field for greater sensitivity in a voice

coil, better bass response and higher overall sound quality. It features re-engineered 8.6mm neodymium drivers that are responsive to high frequencies and ensure pure sound clarity.

In-line remote with mic



The built-in microphone lets you easily switch from music listening to taking phone calls - easily, so you'll always stay connected

Oval sound tubes

Your in-ear headphones are precisely designed to fit any ear. Its ergonomic oval sound tube and curved architecture ensure an optimized, secure and comfortable fit – always.

Silicon caps in three sizes



Your in-ear headphones come with a choice of 3 ear caps – from small to large – so you can select the perfect fit for your ears.

SHE9105RD/27

Specifications

Sound

- Acoustic system: Semi-closed
- Frequency response: 7 - 25 000 Hz
- Diaphragm: Mylar dome
- Impedance: 16 Ohm
- Magnet type: Neodymium
- Type: Dynamic
- Voice coil: Copper
- Speaker diameter: 8.6 mm
- Sensitivity: 108 dB
- Maximum power input: 30 mW

Connectivity

- Connector: 3.5 mm stereo
- Type of cable: OFC
- Cable Connection: two-parallel, symmetric
- Finishing of connector: gold-plated
- Cable length: 1.2 m

Packaging dimensions

- UPC: 6 09585 24794 9

Design

- Color: Red



Issue date 2024-03-08

Version: 1.0.1

UPC: 6 09585 24794 9

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com