



Philips
Universal remote control

5 out of 9 AV devices



SRU5150



Guided setup via LCD display

Operates more than 1000 brands

Your devices are more easily and quickly installed using the new SRU5150! The combination of an LCD display with guided information and a simplified quick start guide, ensure your remote is set up properly in no time!

Single control solution for most devices and brands

- 5-in-1 controller for your audio/video devices
- Easily add and label extra functionality
- Ready for use with Philips equipment

Quick and easy setup

- Simplified quick start guide for fast guided setup
- Convenient IR learning from another remote
- URC support service via dedicated website

Great convenience

- Ergonomic shape enables comfortable control
- Easy to use grouped functions
- LCD screen with backlighting for convenience in the dark
- Low battery indication shows when to refresh batteries
- Batteries are included for unwrap-and-zap

PHILIPS
sense and simplicity

Specifications

Convenience

- Universal IR database: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Programme up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu Control, Colour/Brightness control, Teletext keys, Fast text keys, Previous programme, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu Control
- SAT/CBL functions: Digit keys, Menu Control, Guide, info, Favourites, Text functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: GB/F/D/NL/DK/S/N/FIN
- Number of keys: 40
- Pre-programmed for Philips
- Regulatory Approvals: CE Mark
- Splash-proof

Accessories

- Battery: Yes, 1.5 V Battery R03/AAA

Infrared Capabilities

- Transmitting LEDs: 1

- Universal IR code database
- Number of brands in database: Over 1100
- Carrier frequency range: 24–55 kHz
- Transmission angle: 90 degree
- Operating distance: 33 ft (10 m)
- Learning IR codes
- Learning frequency range: 20 kHz to 70 kHz and 455 kHz

Power

- Battery lifetime: 12 months
- Number of batteries: 2
- Battery type: AAA

Outer Box

- Quantity: 6
- EAN/UPC/GTIN: 87 10895 93606 4
- Height: 172 mm
- Length: 312 mm
- Width: 151 mm

Packaging Data

- 12NC: 908210006487
- EAN/UPC/GTIN: 87 10895 93605 7
- Height: 33 mm
- Length: 304 mm
- Width: 157 mm

Highlights

Backlight on screen

Backlighting is a feature that illuminates the LCD screen or keypad for use in the dark. The two most common types of backlighting are LED and electroluminescent (EL). Remotes backlit with LEDs are typically bright but uneven with a yellow or green colour, while EL panels are smooth with blue, white or green shades.

Low battery indication

To promptly be aware when the batteries need to be recharged or replaced.

Simplified quick start guide

Simplified quick start guide provides assistance in setting up a universal remote control. Instead of typing in 3- or 4-digit codes, an LCD screen is incorporated into the remote to guide you through the setup. Additionally, the quick start guide provides extra information to that displayed on the LCD screen for fast setup.

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

5-in-1 remote control

The universal remote control allows you to programme and operate up to 5 devices from almost any brand. A universal database of infrared codes is incorporated to enable easy installation of your TV, TV combi, VCR, DVD, DVD recorder, satellite or digital terrestrial receiver, cable decoder, amplifier, home theatre system or receiver.

Add extra functionality

Improved way of adding and labelling functions makes it easier and faster to add extra functionality. So, no more missing functions.



Issue date 2009-10-14

Version: 3.0.10

12 NC: 8670 000 26735
EAN: 87 12581 31323 4

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com