



Philips
Micro music system

CD, FM
4W



MC1000

All-in-one Micro System

Obsessed with sound

Tune in to superb sound from a surprisingly compact and sleek design. The MC1000 Micro System will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- MP3 Link for portable music playback
- FM tuner for radio enjoyment
- Dynamic Bass Boost for deep and dramatic sound

Fits any space, any lifestyle

- Compact design

PHILIPS

Specifications

Sound

- Output Power: 2x2W RMS / 2x4W music power
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost

Loudspeakers

- Main Speaker: 3" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program
- Loader Type: Top

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo

Rewritable



Connectivity

- Other connections: FM fixed pigtail antenna
- Audio Connections: 3.5mm Line in

Convenience

- Loader type: top

Accessories

- Included accessories: IFU / User Manual, World Wide Warranty leaflet, MP3 Line-in cable

Dimensions

- Product dimensions (WxDxH): 450 mm x 208.5 mm x 158 mm

Highlights

Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2014-06-12

Version: 1.0.4

12 NC: 8670 000 87824
EAN: 87 12581 63793 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com