

Philips
Micro music system

CD, MP3-CD, USB, FM

MCM3350



Rich and powerful sound

Obsessed with sound

Listen to all your favourites on your portable music player with USB Direct and Audio in. This Philips Micro system also plays MP3-CD and CD-R/RW, and features Bass Reflex speakers for powerful and dramatic bass.

Unlimited listening pleasure

- Audio-in for portable music playback
- Play MP3-CD, CD and CD-R/RW
- USB Direct for easy MP3 music playback

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control
- 130 W RMS Maximum output power

Easy to use

- Motorised CD loader for convenient access
- Digital tuning with preset stations for extra convenience

PHILIPS

Highlights

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3)". .MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

130 W RMS Maximum output power

130 W RMS Maximum output power



Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set balanced, clear, powerful, warm and bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalising technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Specifications

Sound

- Sound Enhancement: Digital Sound Control
- Maximum output power (RMS): 130 W

Loudspeakers

- Loudspeaker types: Dome tweeter
- Main Speaker: 2-way, 4" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search
- Loader Type: Tray, Motorised
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Auto digital tuning
- RDS: Station Name, Programme Type
- Station presets: 20
- Tuner Enhancements: Auto Store
- Tuner Bands: FM Stereo
- Antenna: FM antenna (75 ohm)

Connectivity

- USB: USB host
- Headphones: 3.5 mm
- 3.5 mm stereo line in: Audio in
- Other connections: FM Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: VFD display
- Sleep timer

Accessories

- Included accessories: FM antenna, World Wide Warranty leaflet
- Remote control
- User Manual: Multi-language

Power

- Power supply: 110-127 V/220-240 V, ~50-60 Hz

Dimensions

- Main unit width: 249 mm
- Main unit height: 128 mm
- Main unit depth: 275 mm
- Main speaker dimensions (W x D): 140 x 210 mm
- Gross weight: 7.4 kg
- Main speaker height: 262 mm
- Net weight: 6.2 kg
- Packaging depth: 281 mm
- Packaging height: 337 mm
- Packaging width: 486 mm



Issue date 2016-06-17

Version: 2.0.5

12 NC: 8670 001 22806
EAN: 04 89518 56061 18

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com