



Philips
Wireless Hi-Fi Headphone

- Over-ear
- Silver

SHC5100



Wireless freedom

Fully rechargeable wireless headphones

No more hassle with cables; you can feel free to move around at home for music enjoyment. With the rechargeable and lightweight design of these Philips SHC5100/10 headphones, they're comfortable for extended use.

The perfect wireless listening experience

- 32 mm speaker driver delivers high-performance sound
- FM Wireless transmission for freedom of movement

Comfortable for long use

- Self-adjusting inner headband
- Lightweight design improves comfort for prolonged use.

Convenience

- Fully rechargeable
- Choose from 2 channels to minimise interference

PHILIPS

Specifications

Sound

- Acoustic system: Closed
- Frequency response: 20 - 20,000 Hz
- Magnet type: Neodymium
- Sensitivity: 100 dB
- Speaker diameter: 32 mm

Tuner/Reception/Transmission

- Channel separation: > 30 dB
- Pilot tone frequency: 19 kHz
- Effective range: 100 m
- Carrier frequency range: 863.0 - 865.0 MHz
- Modulation: FM
- Number of channels: 2

Convenience

- Battery charging indication
- Double PLL
- Operating time: ~10 hours
- Automatic power off

Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12 V/

200 mA

Outer Carton

- Gross weight: 3.72 kg
- Net weight: 1.968 kg
- Tare weight: 1.752 kg
- Number of consumer packages: 3
- Outer carton (L x W x H): 39 x 26 x 32.5 cm
- GTIN: 1 69 23410 70493 5

Packaging dimensions

- Packaging dimensions (W x H x D): 24 x 32 x 12.2 cm
- Gross weight: 1.032 kg
- Net weight: 0.656 kg
- Tare weight: 0.376 kg
- Number of products included: 1
- Packaging type: Display
- EAN: 69 23410 70493 8
- Type of shelf placement: Both

Product dimensions

- Product dimensions (W x H x D): 19.5 x 20 x 10 cm
- Weight: 0.308 kg

Highlights

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

Self-adjusting inner headband

Typically, headphones worn outdoors are adjustable by sliding an extendable headband into position. This can be inconvenient as it usually has to be done every time you use them. But now you can get your music fix faster and easier thanks to the flexible, self-adjusting inner headband on these headphones, which automatically adjusts to your head's shape and size.

Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wear.

FM Wireless transmission

With high-frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

Fully rechargeable

The headphones are designed to be used with rechargeable batteries. No worries about cost for repeated use.

2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.



Issue date 2013-06-14

Version: 6.3.7

12 NC: 8670 000 66233
EAN: 69 23410 70493 8

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com