



Philips Design collection
Cordless phone with
answering machine

Slim line
Black



ID5551B

Design collection

When beauty is the call, the ID555 is the answer. This "Design collection" phone is made to delight senses with its elegant slim lines and a pure sound to match. The ID555 is the perfect addition to the most exclusive home interior.

Exclusive design

- Stylish black glossy finish
- Extra slim design

Never miss a call

- Digital answering machine
- 30-minute recording time
- Message-counter on Base

Pure convenience

- Bright blue illuminated display & keypad
- 200-name phonebook
- Speakerphone - Talk handsfree

Eco-designed

- Very low energy consumption
- Automatic reduction of the emitted power

Specifications

Picture/Display

- Backlight
- Backlight color: Blue
- Display colors: Black & White
- Lines of text: 5
- Main Display Technology: FSTN
- Main Display Type: Full Graphic

Sound

- Handset ringers: Polyphonic
- Volume Control: Volume Control up/down

Convenience

- Alarms: Alarm Clock
- Base Station keys: Answering machine keys, Paging key
- Battery charging indication
- Call Management: Call Waiting*, Caller ID*, Conference Call, Explicit Call Transfer, Microphone mute
- Ease of Use: Keypad Lock, Menu Control
- Function: Easy Call
- Multi base capability: 1
- Multi handset capability: Up to 5 handsets
- Signal strength indication
- VIP group with own melody: Yes for each phonebook entry
- Backlit keypad: Yes (Blue)
- Speakerphone - talk handsfree

Network Features

- Antenna: Integrated on base, Integrated on handset
- Compatible: GAP
- Dialing: Tone, Pulse

Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

Answering Machine

- Plug & Play Answering machine
- Recording time capacity: Up to 30 min.
- Message counter on base

Memory Capacity

- Call log entries: 50
- Phonebook: 200 names and numbers
- Redial List Capacity: 10

Dimensions

- Base dimensions: 128 x 69 x 85mm
- Handset dimensions: 144 x 43 x 14.5mm

Power

- Battery Capacity: 500 mAh
- Kind of Battery: Rechargeable
- Mains power: AC 220-240V - 50Hz
- Number of batteries: 1 battery-pack per handset
- Standby time: Up to 130 hours
- Talk time: Up to 10 hours

Highlights

Speakerphone - Talk handsfree

Handsfree mode uses a built-in loud speaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or take notes during a call.

Very low energy consumption

Thanks to a high efficiency power supply, the overall energy consumption is reduced by more than 50% compared to a conventional power supply.

Automatic power reduction

Thanks to an intelligent embedded system, the transmitted power is permanently controlled and optimized depending on the distance between handset and base unit.



Issue date 2019-06-11

Version: 3.0.6

12 NC: 8670 000 41197
EAN: 87 12581 43396 3

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com