

Philips  
Universal Remote Control

4in1 TV/DVD/SAT/AMP

SRU740NC



## Ultra flat

Stylish silver universal remote control that gives maximum functionality for most brands of TV, VCR, DVD, satellite receiver or cable set-top box.

### Single control solution for most devices & brands

- Ready for use with Philips equipment
- 4-in-1 remote for your TV, STB, DVD and Receiver

### Great convenience

- Battery low indication shows when to refresh batteries
- Dedicated keys for moving around menus
- A light indicates current active device mode
- Ultra flat design matching flat home entertainment devices

### Quick and easy set-up

- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- Automatically searches for your equipment brand
- URC support service via dedicated website

**PHILIPS**  
sense and simplicity

## Specifications

### Convenience

- **Universal IR database:** TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- **TV functions:** Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Colour/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- **Teletext enhancements:** Fast text
- **VCR functions:** Transport keys (6), Showview, VCR plus, Menu control
- **DVD functions:** Transport keys, System menu control, Disc menu control, Digit keys
- **SAT/CBL functions:** Digit keys, Menu control, Guide, info, Favourites, Text functions
- **Ease of Installation:** Autosearch
- **Installation steps:** 2
- Copy key function
- **Language support:** GB/F/D/NL/I/E
- **Languages in manual:** GB/F/D/NL/DK/S/N/FIN/I/E/P
- **Number of keys:** 48

- Pre-programmed for Philips
- **Regulatory Approvals:** CE Mark
- Splash proof

### Infrared Capabilities

- **Operating distance:** 7 m
- **Transmitting LEDs:** 1
- Universal IR code database
- **Number of brands in database:** Over 300
- **Carrier frequency range:** 24 - 55 kHz
- **Transmission angle:** 90 degree

### Dimensions

- **Master carton quantity:** 6

### Power

- **Battery lifetime:** 12
- **Number of batteries:** 2

### Accessories

- **Battery:** Yes, CR2025 Coin cell Battery 3V Lithium

## Product highlights

### 4in1 home entertainment remote

Replace a table full of remote controls with one unit that'll operate your TV, satellite receiver (or cable STB set-top box) DVD player/recorder and receiver (AMP), regardless of the brand or model.

### Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

### Ultra flat

A remote with ultra flat design is slimmer than a standard remote. This is made possible by replacing the standard batteries by coin cell batteries (the size of a coin) that take less space.

### Dedicated menu keys

Dedicated keys to move easily around your equipment's menus mean simple one finger operation without having to press shift or function shift keys

### Device mode indicator

Small lights keep you informed about which device mode is currently active.

### Battery-low indication

To know in time when the batteries need to be recharged or replaced.

### Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2007-12-07

Version: 2.0

12 NC: 9082 100 05062  
EAN: 87 10895 86553 1

© 2007 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)