

Philips Micro Hi-Fi System

MCM302

Enjoy music in rich sound

with USB Direct playback

Enjoy rich sound with the Philips Micro Hi-Fi system MCM302. Playback your favourite portable music using the USB Direct or MP3 Link. Digital Sound Control optimises your music style settings. Stylishly designed with high-quality speakers.

Unlimited listening pleasure

- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- · Dynamic Bass Boost for deep and dramatic sound
- 2×25 W RMS/2 \times 50 W Music Power
- · Loudness for bass and treble enhancement

Easy to use

- Motorised CD loader for convenient access
- Radio Data System for station information and data services
- · Wake-Up and Sleep Timer



Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link for portable music

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

USB Direct-MP3/WMA

With the USB Direct mode, you can simply select the music on a USB device and playback all your content. All you have to do is plug in your USB device to playback music or export content from the device.

Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. With the Loudness feature activated, the bass and treble will be amplified so you can savour a more balanced sound perception overall.

















Specifications

Sound

- Output Power: 2 x 25 W RMS/2 x 50 W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness

Loudspeakers

Main Speaker: Bass Reflex Speaker System, 4" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play, Fast Forward/Reverse
- ID3-tag support
- · Loader Type: Tray, Motorised
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- · Auto digital tuning
- RDS: Station Name, RDS Clock Set, Programme Type
- Station presets: 20
- Tuner Enhancements: Auto Store

Connectivity

• Headphones: 3.5 mm

- Other connections: FM Antenna
- Audio Connections: 3.5 mm Line in, Analogue Audio In (L/R)
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- · Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

Accessories

- Included accessories: FM antenna, AC Power Cord, World Wide Warranty leaflet
- Remote control: 40-key remote with Lithium battery
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages

Dimensions

- Set dimensions (W \times H \times D): 200 \times 120 \times 265 mm
- Main speaker dimensions (W x H x D): 150 x 250 x 165 mm
- Packaging dimensions (W x H x D): $520 \times 200 \times 375 \text{ mm}$
- Weight incl. Packaging: 7.5 kg

Power

• Power supply: 220-240 V, 50 Hz



Issue date 2013-05-10

Version: 1.0.7

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 50902 EAN: 87 12581 47359 4

www.philips.com