

Philips  
Micro Hi-Fi System

MP3/WMA-CD playback  
USB Direct

MCM177



## Great sound in a stylish design

with USB Direct playback

Specifically designed for one who appreciates the ultimate in technology and style, the system exudes finesse and quality. With USB Direct, you can play and remote control your MP3/WMA files from your portable player & USB storage devices.

### Enrich your sound experience

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 20W RMS total output power

### Easy to use

- FM digital tuning with presets
- Wake up and sleep timer functions

### Refined in sound and look

- Elegant wood-finished speakers

# PHILIPS

# Highlights

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically

adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually

get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Loudness

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.



# Specifications

## Sound

- Output Power: 2x10W RMS / 2x20W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness

## Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System

## Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

## Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 20
- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store

## Connectivity

- Other connections: FM Antenna
- Headphone: 3.5 mm
- Audio Connections: 3.5mm Line in, Analogue

## Audio In (L/R)

- USB: USB host

## Convenience

- Display Type: LCD
- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Backlight color: Blue
- Eco Power Standby: 1 watt

## Accessories

- Included accessories: FM antenna, World Wide Warranty leaflet
- Remote control: 40-key with Lithium batteries
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages
- AC/DC Adaptor: Switching power supply

## Dimensions

- Set dimensions (W x H x D): 232 x 85 x 275 mm
- Main speaker dimensions (W x H x D): 160 x 250 x 180 mm
- Packaging dimensions (W x H x D): 554 x 405 x 275 mm
- Weight incl. Packaging: 6.9 kg

## Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2014-02-06

Version: 2.0.6

12 NC: 8670 000 35823  
EAN: 87 12581 38538 5

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)