



Philips
Wireless Hi-Fi Headphone

SBCHC844 I



2 headphones included

Wireless

No hassles with cables, just the freedom to move around and enjoy music with your FM wireless stereo FM headphone - plus a second headphone for a friend.

You'll forget you're wearing them!

- 3-way adjustment for a better fit and bass performance
- Lightweight design improves comfort for prolonged use.

The perfect wireless listening experience

- ALC helps prevent audible distortion of input signals
- 32 mm speaker driver delivers high-performance sound

Always ready to go

- FM Wireless transmission for freedom of movement
- 2 headphones means you can share your music with a friend
- Reduces costs by using rechargeable batteries

PHILIPS
sense and simplicity

Specifications

Sound

- **Acoustic system:** Closed
- **Frequency response:** 10–20,000 Hz
- **Magnet type:** Ferrite
- **Sensitivity:** 100 dB
- **Speaker diameter:** 32

Tuner/Reception/Transmission

- **Pilot tone frequency:** 19 kHz
- **Effective range:** 100
- **Carrier frequency range:** 863.0 - 865.0 MHz
- **Channel separation:** > 30 dB
- **Modulation:** FM
- **Number of channels:** 2

Convenience

- Battery charging indication
- Automatic power off
- **Operating time:** +/- 15 hours
- Battery low indication
- Double PLL

Power

- **Power supply headphone:** 2 x 1.5 V NiMH R03/AAA
- **Power supply transmitter:** AC/DC adapter 12 V/200 mA

Outer Box

- **EAN:** 87 10895 84384 3
- **Number of consumer packages:** 6
- **Gross weight:** 8.761 kg
- **Outer carton (L x W x H):** 47.4 x 45.4 x 34.5 cm
- **Net weight:** 4.878 kg
- **Tare weight:** 3.883 kg

Packaging dimensions

- **EAN:** 87 10895 80703 6
- **Number of products included:** 1
- **Packaging type:** Box
- **Packaging dimensions (W x H x D):** 14.9 x 21.4 x 30.2 cm
- **Gross weight:** 1.222 kg
- **Net weight:** 0.813 kg
- **Tare weight:** 0.409 kg

Product highlights

3-way adjustable ear shells

Enjoy a comfortable fit and experience better bass performance thanks to the three-way adjustable ear shells that fit naturally around your ears.

Lightweight design

The durable, lightweight quality materials enhance comfort for extended wearing.

Automatic Level Control (ALC)

This smart electronic circuit ensures that the audio input level is automatically adjusted to the right level, preventing distortion and preserving your listening enjoyment.

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

FM Wireless transmission

With high-frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

2 headphones included

With two headphone sets, you can share the 'personal' listening experience with a friend.

Rechargeable system

The headphone set incorporates facilities for recharging the batteries.



Issue date 2009-02-12

Version: 6.0.10

12 NC: 9082 100 02652
EAN: 87 10895 80703 6

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com