

Philips  
Portable DVD Player

17.8 cm/7" widescreen LCD

PET727



## Movies that travel with you

with 3 hours playtime and USB connection

Enjoy your movies anytime, anywhere! The portable PET727 DVD player featuring 7" TFT LCD display lets you indulge in the pleasure of enjoying DVD/DivX® movies, MP3-CD/CD music and JPEG photos on the go.

### Play your movies, music and photos on the go

- DVD, DVD+/-R, DVD+/-RW, (S)VCD, CD compatible
- DivX Certified for standard playback of DivX videos
- MP3-CD, CD and CD-RW playback
- View JPEG images from picture disc

### Enrich your AV entertainment experience

- 17.8 cm/7" TFT color LCD display in 16:9 wide screen format
- Enjoy movies in 16:9 widescreen format
- Built-in stereo speakers

### Extra touches for your convenience

- Enjoy up to 3 hours playback with a built-in battery\*
- USB connection for video, photo and music playback
- Car mount pouch included for easy in-car use
- AC adaptor, car adaptor and AV cable included

**PHILIPS**

# Highlights

## 3 hours built-in battery\*



This Philips player comes with a compact built-in rechargeable battery for long-lasting power. Up to 3 hours of continuous movie, photo and music playback enjoyment can be achieved on a single charge. Just plug in the power cable to recharge the player - it's that simple.

## 18 cm/7" TFT color LCD (16:9)



The color LCD display brings images to life, showing off your treasured photos, favorite movies and music with the same 'real life' rich detail and vibrant colors as high quality prints. The 16:9 widescreen aspect ratio is standard for universal to high-definition digital television. A native 16:9 aspect ratio means video display without bars at top and bottom of the picture and without the quality loss than comes from scaling, altering an image to fit on a different screen size.

## Car mount pouch



Mount your portable DVD player easily to your car headrest. You can enjoy DVD movies on the road.

## DivX Certified



With DivX® support, you are able to enjoy DivX® encoded videos. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs.

## Enjoy 16:9 widescreen movies



Display and share your movies and digital photos with your friends and family. The 16:9

widescreen aspect ratio is standard for universal to high-definition digital television. A native 16:9 aspect ratio means video display without bars at top and bottom of the picture and without the quality loss than comes from scaling, altering an image to fit on a different screen size.

## MP3-CD, CD and CD-RW playback



MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hours of music.

## USB connection



Simply plug in your portable USB device to the USB connector on your Philips portable DVD player and playback your digital videos, music or photos directly. Now you can share your favorite moments with family and friends.



# Specifications

## Picture/Display

- Display screen type: LCD TFT
- Diagonal screen size (inch): 7 inch
- Resolution: 480(w)x234(H)x3(RGB)
- Brightness: 100 cd/m<sup>2</sup>
- Contrast ratio (typical): 200:1
- LCD panel type: Anti-glare polarizer
- Effective viewing area: 154.1x86.6mm
- Response time (typical): 30 ms

## Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 5mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

## Video Playback

- Playback Media: DVD, DVD+R/+RW, DVD-R/-RW, DVD+R, DVD+RW, SVCD, Video CD, Picture CD, MP3-CD, CD-R/CD-RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: Divx, MPEG4

## Audio Playback

- Compression format: Dolby Digital, MP3
- MP3 bit rates: 32 - 320 kbps
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Joliet

## Connectivity

- DC in: 12V
- Headphone jack: 3.5mm Stereo Headphone x 1
- AV output: Composite (CVBS) x1
- Audio Output - Digital: Coaxial (cinch)

## Convenience

- Battery charging indication
- Shock proof

## Accessories

- AC/DC Adaptor: DC-IN 12V, 110-240v, 50/60Hz
- Remote control: Slim remote
- Cables: 1 x AV Cables
- User Manual: Multi languages
- Car kit: cigarette outlet adaptor, 12vDC
- Included accessories: Travel pouch

## Power

- Battery lifetime: Up to 3hrs \*
- Battery Type: Built-in battery

## Dimensions

- Master carton dimensions: 258 x 230 x 422 mm
- Master carton quantity: 3
- Master carton weight: 5 kg
- Packaging dimensions (W x H x D): 242 x 198 x 133 mm
- Product dimensions (W x H x D): 199 x 40 x 159 mm
- Product weight: 0.66 kg
- Packaging type: D-box



Issue date 2014-02-12

Version: 1.0.4

12 NC: 8670 000 59409  
EAN: 87 12581 52121 9

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* DivX, DivX Certified, and associated logos are trademarks of DivXNetworks, Inc. and are used under license.

\* Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of charge cycles vary by use and settings.

\* Battery life varies by use and settings.

\* Battery life of playtime is approximate and may vary depending on application condition. To optimize battery life, user should turn LCD backlight to minimum, connect to headphones (not built-in speakers) and listen at medium volume level, and use the product at room temperature.